

[Click Here](#)























Troubleshoot Linear garage door opener photo eye issues by aligning the photo eye, checking for continuity in the wires, and cleaning the housing. Additionally, check the safety sensors and adjust the travel down setting if the door keeps going back up. If the infrared safety beam is blocked or out of alignment, the opener will ignore signals from remote controls. Ensure that the wires for the door control are not shorted and that the door control itself is not faulty. Follow these troubleshooting steps to fix common issues with your Linear garage door opener. Credit: youtube.comHaving issues with your Linear garage door opener's photo eye? Learn how to troubleshoot and fix issues such as misalignment, dirty housing, and continuity problems. Check out helpful videos on YouTube for step-by-step instructions. In linear garage door openers, the photo eye system consists of a sender and a receiver. The sender emits an infrared beam, while the receiver detects the beam. It's essential to understand the difference between these two components to troubleshoot any issues effectively. The photo eye system is equipped with a green light indicator. If the system is functioning correctly, this green light will remain solid. However, if you notice that the green light is flashing or not lit at all, it is an indication of an issue that needs troubleshooting. Proper alignment of the photo eye system is crucial for its optimal functioning. If the sender and receiver are not aligned correctly, it can lead to issues with the garage door opener. Ensure that both the sender and receiver are facing each other and aligned properly to maintain a secure connection. Several factors can lead to photo eye failure in linear garage door openers. Some common causes include dirt or debris obstructing the photo eye lenses, misalignment of the sender and receiver, damaged or worn-out wiring, or electrical problems within the opener system. To maintain the functionality of the photo eye system, it is essential to clean the housing regularly. Use a soft cloth or a mild cleaning solution to remove any dirt or debris that may have accumulated on the lenses. Inspect the wiring for any issues, such as fraying or loose connections, and ensure that the wires are properly secured. If you are unsure about the proper functioning of the photo eye system, it's always best to consult a professional technician. If your Linear garage door opener not closing properly? Don't worry, there's an easy fix! In this article, we'll walk you through the troubleshooting steps to get your garage door functioning smoothly again. One common reason why a Linear garage door opener may not be closing is due to issues with the safety sensors. These sensors are designed to detect any obstacles in the path of the closing door and automatically reverse it to prevent damage or accidents. Here's how you can check the safety sensors: Inspect the sensor lights: Make sure that both the sender and receiver sensors have their lights on and are properly aligned. These sensors are usually placed on each side of the garage door, near the bottom. The indicator lights should be solid, not flickering or off. Clean the sensor housing: Dust, dirt, or other debris can interfere with the sensor's operation. Use a dry cloth to gently clean the sensor housing, ensuring there's no obstruction. Check the wires for continuity: Ensure that the wires connecting the sensors to the opener are not damaged or loose. If you notice any issues, you may need to repair or replace the wiring. By following these steps, you can often resolve the issue with the safety sensors and get your Linear garage door opener back to closing properly. In order for the safety sensors to function correctly, proper alignment is crucial. Here's how you can ensure the alignment: Steps to Instructions: Step 1 Remove any obstructions: Clear the area around the sensors of any objects that may be blocking the path or causing interference. Step 2 Adjust sensor brackets: Loosen the brackets holding the sensors in place and carefully adjust their positions until they are facing each other directly. Use a level to ensure they are aligned properly. Step 3 Tighten sensor brackets: Once the sensors are aligned, tighten the brackets to secure them in place. Following these alignment steps will help guarantee that the safety sensors are working as intended, allowing your Linear garage door opener to close smoothly and safely. Understanding the basic operation of a linear garage door opener is essential for troubleshooting common issues that may arise. By familiarizing yourself with how the opener works, you can easily identify and resolve any problems that may occur. In this section, we will discuss the basic operation of linear garage door openers and provide troubleshooting tips for common issues. A linear garage door opener is comprised of several components that work together to open and close your garage door. Here is a breakdown of the basic operation: Power supply: The opener is powered by electricity, usually from a standard wall outlet. Motor: The motor is responsible for generating the power needed to open and close the garage door. Drive mechanism: The drive mechanism, often a belt or chain, connects the motor to the garage door and transfers the power. Remote control: The remote control allows you to wirelessly operate the garage door opener from a distance. Safety sensors: Safety sensors are installed near the bottom of the door and detect any obstructions or objects in the path of the closing door, preventing accidents. Despite their reliability, linear garage door openers may encounter issues from time to time. Here are some common problems and troubleshooting tips to resolve them: Remote control not opening or closing: Check if the opener is receiving power and ensure that the motor is functioning properly. Inspect the drive mechanism for any signs of damage or obstructions. Remote control not working: Replace the batteries in the remote control and ensure that the opener is in range. If the problem persists, reprogram the remote control to the opener. Garage door reversing before closing: This issue may be caused by misaligned safety sensors. Inspect the sensors and ensure they are properly aligned and free from any dirt or debris. Weird noises during operation: Lubricate the moving parts of the opener, such as the drive mechanism, to reduce friction. If the noise continues, there may be a mechanical issue that requires professional repair. Intermittent operation: Check the wiring connections of the opener and ensure they are secure. Loose or damaged wires can cause intermittent operation. It is important to note that if you are unable to resolve the issue on your own or if the problem persists, it is best to contact a professional garage door technician. They have the knowledge and expertise to diagnose and repair any complex problems with your linear garage door opener. If you're experiencing issues with your Linear garage door opener, resetting it may help resolve the problem. Resetting the opener is a simple troubleshooting step that can be done in a few easy steps. Below, we've outlined the process to reset your Linear garage door opener. Locate the 'Learn' or 'Smart' button on your garage door opener. This button is usually found on the back or side of the motor unit. Press and hold down the 'Learn' or 'Smart' button for approximately 10-15 seconds. Release the button once the indicator light on the garage door opener starts flashing. After releasing the button, wait for about 30 seconds to allow the opener to reset completely. Test the opener by pressing the remote control or the wall-mounted button to see if the door opens and closes properly. Resetting your Linear garage door opener can often help resolve common issues such as the door not responding to remote or wall button commands. In addition to resetting the opener, you may also consider checking the batteries in your remote control, ensuring that the power source to the opener is stable, and inspecting the safety sensors for any obstructions or misalignment. If the problem persists even after resetting and performing other troubleshooting steps, it may be best to contact a professional garage door technician for further assistance. They can diagnose and repair any underlying issues that may be causing the problem. When it comes to troubleshooting your Linear garage door opener, it's important to familiarize yourself with common issues and their solutions. This will help you identify and resolve any problems you may encounter, ensuring smooth operation of your garage door. In this post, we will discuss two common issues and their solutions with Linear garage door openers: "Garage door keeps going back up" and "Blocked or misaligned infrared safety beam." If your garage door closes partially and then immediately reverses back up, it can be frustrating and inconvenient. Fortunately, this issue can be easily addressed by adjusting the travel down setting of your Linear garage door opener. The travel down setting controls the distance the door needs to travel before fully closing. If the door closes before reaching this set distance, it may have detected an obstacle or safety issue, causing it to reverse. To fix this issue, follow these steps: Locate the travel down adjustment on your Linear garage door opener, usually found on the back of the motor unit. Turn the adjustment screw until the desired travel distance is achieved. By adjusting the travel down setting, you can ensure that your garage door closes completely without encountering any obstacles. If an object obstructs the path of the garage door while it is closing, the infrared safety beam will detect the blockage and cause the door to reverse and fully open. This is a safety feature designed to prevent any damage or injuries. To troubleshoot this issue, follow these steps: Inspect the area around the garage door for any objects that may be blocking the infrared safety beam. Remove any obstructions, such as debris or stored items, that may be interrupting the path of the infrared beam. If there are no visible obstructions, check the alignment of the infrared safety beam sensors. Ensure that they are facing each other directly and aligned properly. Adjust the position of the sensors if necessary, ensuring that they are securely fastened in place. By unblocking or realigning the infrared safety beam sensors, you can prevent unnecessary reversals of your garage door and ensure smooth operation. In conclusion, addressing common issues with Linear garage door openers can be easily done by adjusting the travel down setting and checking for any obstructions or misalignments in the infrared safety beam. By following these troubleshooting steps, you can ensure the proper functioning of your garage door opener and avoid any inconveniences. To reset a linear garage door opener, follow these steps: 1. Locate the "Learn" button on the opener motor. 2. Press and hold the "Learn" button until the indicator light turns on. 3. Release the button and wait for the light to turn off. 4. Press the desired button on your remote control within 30 seconds. 5. The opener will beep or flash to confirm the reset. Make sure you are following the correct steps for your specific opener model. For a detailed guide, visit the YouTube channel "Garage Door Opener Repair" or search for "Linear garage door opener reset" on YouTube. The video provides a step-by-step guide on how to reset your Linear garage door opener. It covers the location of the "Learn" button, how to press and hold it, and how to test the opener after the reset. The video also explains the importance of safety during the reset process and provides tips for troubleshooting common issues. If you are unable to reset your Linear garage door opener, it may be a sign of a more serious problem. In this case, it is recommended to contact a professional garage door technician for assistance. They can diagnose the issue and provide the necessary repairs. Ensure the continued functionality and safety of your Linear garage door opener. If you're in the market for a new garage door opener, you're likely to encounter a critical decision: which garage door opener is best? The answer lies in the chain of best choice. This isn't just a technical choice; it's about convenience, long-term reliability, and value for your money. Whether... If your garage door remote has suddenly stopped working or seems sluggish, chances are high that the battery is dying or completely dead. One of the most common questions homeowners ask in this situation is: "Where can I buy a garage door opener battery?" This... Garage door technology has evolved significantly over the past few decades, offering enhanced convenience, improved safety, and smarter integration with our daily lives. But even as manufacturers like LiftMaster, Chamberlain, and Craftsman develop advanced openers, one essential accessory still stands strong: the keypad. Garage Door Padia Welcome to GarageDoorPadia.com, The ultimate portal for all your garage door needs! We are a passionate team dedicated to providing you with comprehensive and insightful garage door guides, tips, and tricks. It is no fun returning home to a malfunctioning garage door opener. If you own a Linear garage door opener, chances are you have experienced one or two issues with your opener before, and that is completely normal. Openers are equipped with safety and security features, which helps prevent injury and the opener from damaging. So, in this post, you will learn how to troubleshoot Linear garage door opener. Let's get into it! The first step to troubleshooting your Linear garage door opener is to determine if the remote is in good condition. Most Linear opener remotes have a red LED on it that turns on anytime you press a button. If it fails to turn on, you should replace the batteries in the remote. Duracell CR2032 Batteries (Amazon) is a solid replacement battery that works very well with Linear garage door opener remotes. Another way to check if the problem is with your remote is to activate your garage door opener with the wired wall station. If the opener activates, chances are you either have to replace the batteries or the remote. Linear Pro Access, the manufacturers of Linear garage door openers, did an excellent job of how the openers provide error information to the user. The number of times the light on the opener flashes tells you the problem that needs to be fixed. For some models, the indicator light is a small LED, usually red, and located at the back panel of the garage door opener. You may need a step ladder to visibly see the light flashing. For other models, like the LD033 and LD050, errors are indicated with the Light bulb in the opener. This means you can clearly see the light flashing even when on the ground. The second step in troubleshooting a Linear garage door opener is to identify the number of times the light flashes when you press a button on your remote or wired wall station. Perhaps, you can't see the Lamp flashing because your garage door is closed and you are outside. In that case, I suggest you get out of your vehicle and enter your home through the main entry, and then into your garage. Now that you have eyes on your garage door opener, activate it by pressing the remote button and counting the number of times the light flashes. There is no issue at all when the light flashes once. When you are programming Linear garage door openers to work with remotes, a single flash of the light confirms that the remote control code has been successfully stored in memory. That simply means you can now activate your station with the remote. You get a single flash only when you are programming the opener. When the LED or the light bulb on your Linear garage door opener flashes four times, it means the force of the opener is exceeded. Before we dive into the troubleshooting steps, you need to know what a garage door opener refers to the strength it requires to drive the garage door up or down under normal conditions. Your Linear garage door opener does not lift the entire weight of the door up or down; the torsion spring does that. The opener's force simply gives it a push or pull. What causes the force to be exceeded? First, when the torsion spring is broken, secondly, when the garage door tracks are damaged, and thirdly when the door is unbalanced. When any of these problems occur, it will require an excessive amount of energy from the opener to lift the door, and that can damage your opener. So to prevent this from happening, your Linear garage door opener will shut down. Carry out these troubleshooting steps to get this problem fixed. It's important to have your door closed before you follow these steps. Pull the emergency cord down and towards the garage door opener. This will disconnect the garage door from the opener. Open the garage door manually, to about halfway. Now leave the door. For a balanced garage door, it should stay in that position without going up or down. If that's not the case, then your garage door is unbalanced. Now lift the garage door to its fully open position. The garage door should stay up when you leave it. Else it is unbalanced. Call a technician if your door is unbalanced. Attempting to balance your door on your own can lead to severe injury if you are not experienced. However, after troubleshooting and your garage door is in good condition, you may have to adjust the force factor of your garage door opener. Here's how to adjust the force factor for these particular models: LDC0800, LDC0850, and the LDC0852 Press and hold the Up and Down button on the back panel for 3 seconds. Both the green and red LED, as well as the opener lights, will flash twice. It means opener is in the Force Factor settings. Press the up button to increase the force factor, or the down button to decrease it. Press the Learn button to save changes. The lights will flash twice again to confirm changes have been saved. Perform the Safety Reversing Test after adjusting. Place a brick under the garage door, at a position where it is in the way of the door. When the door hits the brick, it must reverse within 2 seconds. If it doesn't, decrease the Force Factor and repeat the test till the door reverses. Here's how to adjust the force factor for these particular models: LD033, LD050, LS050, and LC075 Adjusting the Close Force Locate the open and close force adjustment dials on the sides of your opener To increase the Close Force, turn the Close Force Adjustment dial 1/8 turn at a time, in the clockwise direction, until the door closes fully without reversing. To decrease the Close Force, turn the Close Force Adjustment dial 1/8 turn at a time, in the clockwise direction, until the door opens fully without stopping. To decrease the Close Force, turn the Close Force Adjustment dial 1/8 turn at a time, counterclockwise until the door stops in the middle while going up. NB: Performing the Safety Reversing Test is a crucial step. Failure to do so may result in severe injury or even death if the force is set too high. Also, do not use the Force Adjustment to compensate for a Binding or Sticking door. Also: Chamberlain Garage Door Opener Troubleshooting: Step-by-Step Guide When the LED or the light bulb on your Linear garage door opener flashes five times, it means vacation mode has been activated; hence the garage door won't open. Linear garage door openers have a feature called vacation mode. This is a handy security feature for homeowners who are traveling, on vacation, or simply not at home. With this feature activated, no one can get access to your garage, not even with your remote. To be able to open your garage door with your remote, simply unlock the vacation switch on the wall station. Problem solved. When the LED or the light bulb on your Linear garage door opener flashes six times, it means the motor has run for more than 30 seconds. Linear garage door openers have been designed to know how long it takes to fully open or close a garage door, and the maximum time it takes is about 30 seconds. When it exceeds that, the lights will flash six times. Call a Linear garage door opener expert in your area to come and fix it. This is usually a mechanical or electrical failure and requires an expert to handle it. When the LED or the light bulb on your Linear garage door opener flashes seven times, it means the encoder has detected an error. Two things can happen when this error is detected. It is either the garage door reverses anytime you activate it, or it won't open at all. The first thing to check when this happens is an obstruction in the doorway. If there is anything under the garage door or closer to the doorway, if there is something there, chances are it is blocking the signal from the sender to the receiving sensor. And that is the reason why the door isn't closing. Get rid of anything in the doorway. The two sensors on each side of the door are supposed to face each other. So check if they are properly aligned. A simple way to do that is to take a look at the sensor with the two LEDs. That is the sending sensor. Both the green and red LEDs should be on. If the red LED is off, then the sensors are not aligned. If that's the case, then clean the lenses on both sensors. And then adjust the sensors so they can face each other. Continue tweaking and adjusting till the red LED turns back on. Also: Liftmaster Garage Door Opener Troubleshooting: Step-by-Step Guide When the LED or the light bulb on your Linear garage door opener flashes four times, it means the force of the opener is exceeded. Before we dive into the troubleshooting steps, you need to know what a garage door opener refers to the strength it requires to drive the garage door up or down under normal conditions. Your Linear garage door opener does not lift the entire weight of the door up or down; the torsion spring does that. The opener's force simply gives it a push or pull. What causes the force to be exceeded? First, when the torsion spring is broken, secondly, when the garage door tracks are damaged, and thirdly when the door is unbalanced. When any of these problems occur, it will require an excessive amount of energy from the opener to lift the door, and that can damage your opener. So to prevent this from happening, your Linear garage door opener will shut down. Carry out these troubleshooting steps to get this problem fixed. It's important to have your door closed before you follow these steps. Pull the emergency cord down and towards the garage door opener. This will disconnect the garage door from the opener. Open the garage door manually, to about halfway. Now leave the door. For a balanced garage door, it should stay in that position without going up or down. If that's not the case, then your garage door is unbalanced. Now lift the garage door to its fully open position. The garage door should stay up when you leave it. Else it is unbalanced. Call a technician if your door is unbalanced. Attempting to balance your door on your own can lead to severe injury if you are not experienced. However, after troubleshooting and your garage door is in good condition, you may have to adjust the force factor of your garage door opener. Here's how to adjust the force factor for these particular models: LDC0800, LDC0850, and the LDC0852 Press and hold the Up and Down button on the back panel for 3 seconds. Both the green and red LED, as well as the opener lights, will flash twice. It means opener is in the Force Factor settings. Press the up button to increase the force factor, or the down button to decrease it. Press the Learn button to save changes. The lights will flash twice again to confirm changes have been saved. Perform the Safety Reversing Test after adjusting. Place a brick under the garage door, at a position where it is in the way of the door. When the door hits the brick, it must reverse within 2 seconds. If it doesn't, decrease the Force Factor and repeat the test till the door reverses. Here's how to adjust the force factor for these particular models: LD033, LD050, LS050, and LC075 Adjusting the Close Force Locate the open and close force adjustment dials on the sides of your opener To increase the Close Force, turn the Close Force Adjustment dial 1/8 turn at a time, in the clockwise direction, until the door closes fully without reversing. To decrease the Close Force, turn the Close Force Adjustment dial 1/8 turn at a time, counterclockwise until the door stops in the middle while going up. NB: Performing the Safety Reversing Test is a crucial step. Failure to do so may result in severe injury or even death if the force is set too high. Also, do not use the Force Adjustment to compensate for a Binding or Sticking door. Also: Chamberlain Garage Door Opener Troubleshooting: Step-by-Step Guide When the LED or the light bulb on your Linear garage door opener flashes five times, it means vacation mode has been activated; hence the garage door won't open. Linear garage door openers have a feature called vacation mode. This is a handy security feature for homeowners who are traveling, on vacation, or simply not at home. With this feature activated, no one can get access to your garage, not even with your remote. To be able to open your garage door with your remote, simply unlock the vacation switch on the wall station. Problem solved. When the LED or the light bulb on your Linear garage door opener flashes six times, it means the motor has run for more than 30 seconds. Linear garage door openers have been designed to know how long it takes to fully open or close a garage door, and the maximum time it takes is about 30 seconds. When it exceeds that, the lights will flash six times. Call a Linear garage door opener expert in your area to come and fix it. This is usually a mechanical or electrical failure and requires an expert to handle it. When the LED or the light bulb on your Linear garage door opener flashes seven times, it means the encoder has detected an error. Two things can happen when this error is detected. It is either the garage door reverses anytime you activate it, or it won't open at all. The first thing to check when this happens is an obstruction in the doorway. If there is anything under the garage door or closer to the doorway, if there is something there, chances are it is blocking the signal from the sender to the receiving sensor. And that is the reason why the door isn't closing. Get rid of anything in the doorway. The two sensors on each side of the door are supposed to face each other. So check if they are properly aligned. A simple way to do that is to take a look at the sensor with the two LEDs. That is the sending sensor. Both the green and red LEDs should be on. If the red LED is off, then the sensors are not aligned. If that's the case, then clean the lenses on both sensors. And then adjust the sensors so they can face each other. Continue tweaking and adjusting till the red LED turns back on. Also: Liftmaster Garage Door Opener Troubleshooting: Step-by-Step Guide When the LED or the light bulb on your Linear garage door opener flashes four times, it means the force of the opener is exceeded. Before we dive into the troubleshooting steps, you need to know what a garage door opener's force is, and why it's important. Force of a garage door opener refers to the strength it requires to drive the garage door up or down under normal conditions. Your Linear garage door opener does not lift the entire weight of the door up or down; the torsion spring does that. The opener's force simply gives it a push or pull. What causes the force to be exceeded? First, when the torsion spring is broken, secondly, when the garage door tracks are damaged, and thirdly when the door is unbalanced. When any of these problems occur, it will require an excessive amount of energy from the opener to lift the door, and that can damage your opener. So to prevent this from happening, your Linear garage door opener will shut down. Carry out these troubleshooting steps to get this problem fixed. It's important to have your door closed before you follow these steps. Pull the emergency cord down and towards the garage door opener. This will disconnect the garage door from the opener. Open the garage door manually, to about halfway. Now leave the door. For a balanced garage door, it should stay in that position without going up or down. If that's not the case, then your garage door is unbalanced. Now lift the garage door to its fully open position. The garage door should stay up when you leave it. Else it is unbalanced. Call a technician if your door is unbalanced. Attempting to balance your door on your own can lead to severe injury if you are not experienced. However, after troubleshooting and your garage door is in good condition, you may have to adjust the force factor of your garage door opener. Here's how to adjust the force factor for these particular models: LDC0800, LDC0850, and the LDC0852 Press and hold the Up and Down button on the back panel for 3 seconds. Both the green and red LED, as well as the opener lights, will flash twice. It means opener is in the Force Factor settings. Press the up button to increase the force factor, or the down button to decrease it. Press the Learn button to save changes. The lights will flash twice again to confirm changes have been saved. Perform the Safety Reversing Test after adjusting. Place a brick under the garage door, at a position where it is in the way of the door. When the door hits the brick, it must reverse within 2 seconds. If it doesn't, decrease the Force Factor and repeat the test till the door reverses. Here's how to adjust the force factor for these particular models: LD033, LD050, LS050, and LC075 Adjusting the Close Force Locate the open and close force adjustment dials on the sides of your opener To increase the Close Force, turn the Close Force Adjustment dial 1/8 turn at a time, in the clockwise direction, until the door closes fully without reversing. To decrease the Close Force, turn the Close Force Adjustment dial 1/8 turn at a time, counterclockwise until the door stops in the middle and reverse while going down. Perform the Safety Reversing Test after adjusting. Place a brick under the garage door, at a position where it is in the way of the door. When the door hits the brick, it must reverse within 2 seconds. If it doesn't, decrease the Close Force and repeat the test till the door reverses. Adjusting the Open Force Locate the open and close force adjustment dials on the sides of your opener To increase the Open Force, turn the Close Force Adjustment dial 1/8 turn at a time, in the clockwise direction, until the door opens fully without stopping. To decrease the Close Force, turn the Close Force Adjustment dial 1/8 turn at a time, counterclockwise until the door stops in the middle while going up. NB: Performing the Safety Reversing Test is a crucial step. Failure to do so may result in severe injury or even death if the force is set too high. Also, do not use the Force Adjustment to compensate for a Binding or Sticking door. Also: Chamberlain Garage Door Opener Troubleshooting: Step-by-Step Guide When the LED or the light bulb on your Linear garage door opener flashes five times, it means vacation mode has been activated; hence the garage door won't open. Linear garage door openers have a feature called vacation mode. This is a handy security feature for homeowners who are traveling, on vacation, or simply not at home. With this feature activated, no one can get access to your garage, not even with your remote. To be able to open your garage door with your remote, simply unlock the vacation switch on the wall station. Problem solved. When the LED or the light bulb on your Linear garage door opener flashes six times, it means the motor has run for more than 30 seconds. Linear garage door openers have been designed to know how long it takes to fully open or close a garage door, and the maximum time it takes is about 30 seconds. When it exceeds that, the lights will flash six times. Call a Linear garage door opener expert in your area to come and fix it. This is usually a mechanical or electrical failure and requires an expert to handle it. When the LED or the light bulb on your Linear garage door opener flashes seven times, it means the encoder has detected an error. Two things can happen when this error is detected. It is either the garage door reverses anytime you activate it, or it won't open at all. The first thing to check when this happens is an obstruction in the doorway. If there is anything under the garage door or closer to the doorway, if there is something there, chances are it is blocking the signal from the sender to the receiving sensor. And that is the reason why the door isn't closing. Get rid of anything in the doorway. The two sensors on each side of the door are supposed to face each other. So check if they are properly aligned. A simple way to do that is to take a look at the sensor with the two LEDs. That is the sending sensor. Both the green and red LEDs should be on. If the red LED is off, then the sensors are not aligned. If that's the case, then clean the lenses on both sensors. And then adjust the sensors so they can face each other. Continue tweaking and adjusting till the red LED turns back on. Also: Liftmaster Garage Door Opener Troubleshooting: Step-by-Step Guide When the LED or the light bulb on your Linear garage door opener flashes four times, it means the force of the opener is exceeded. Before we dive into the troubleshooting steps, you need to know what a garage door opener refers to the strength it requires to drive the garage door up or down under normal conditions. Your Linear garage door opener does not lift the entire weight of the door up or down; the torsion spring does that. The opener's force simply gives it a push or pull. What causes the force to be exceeded? First, when the torsion spring is broken, secondly, when the garage door tracks are damaged, and thirdly when the door is unbalanced. When any of these problems occur, it will require an excessive amount of energy from the opener to lift the door, and that can damage your opener. So to prevent this from happening, your Linear garage door opener will shut down. Carry out these troubleshooting steps to get this problem fixed. It's important to have your door closed before you follow these steps. Pull the emergency cord down and towards the garage door opener. This will disconnect the garage door from the opener. Open the garage door manually, to about halfway. Now leave the door. For a balanced garage door, it should stay in that position without going up or down. If that's not the case, then your garage door is unbalanced. Now lift the garage door to its fully open position. The garage door should stay up when you leave it. Else it is unbalanced. Call a technician if your door is unbalanced. Attempting to balance your door on your own can lead to severe injury if you are not experienced. However, after troubleshooting and your garage door is in good condition, you may have to adjust the force factor of your garage door opener. Here's how to adjust the force factor for these particular models: LDC0800, LDC0850, and the LDC0852 Press and hold the Up and Down button on the back panel for 3 seconds. Both the green and red LED, as well as the opener lights, will flash twice. It means opener is in the Force Factor settings. Press the up button to increase the force factor, or the down button to decrease it. Press the Learn button to save changes. The lights will flash twice again to confirm changes have been saved. Perform the Safety Reversing Test after adjusting. Place a brick under the garage door, at a position where it is in the way of the door. When the door hits the brick, it must reverse within 2 seconds. If it doesn't, decrease the Force Factor and repeat the test till the door reverses. Here's how to adjust the force factor for these particular models: LD033, LD050, LS050, and LC075 Adjusting the Close Force Locate the open and close force adjustment dials on the sides of your opener To increase the Close Force, turn the Close Force Adjustment dial 1/8 turn at a time, in the clockwise direction, until the door closes fully without reversing. To decrease the Close Force, turn the Close Force Adjustment dial 1/8 turn at a time, counterclockwise until the door stops in the middle while going up. NB: Performing the Safety Reversing Test is a crucial step. Failure to do so may result in severe injury or even death if the force is set too high. Also, do not use the Force Adjustment to compensate for a Binding or Sticking door. Also: Chamberlain Garage Door Opener Troubleshooting: Step-by-Step Guide When the LED or the light bulb on your Linear garage door opener flashes five times, it means vacation mode has been activated; hence the garage door won't open. Linear garage door openers have a feature called vacation mode. This is a handy security feature for homeowners who are traveling, on vacation, or simply not at home. With this feature activated, no one can get access to your garage, not even with your remote. To be able to open your garage door with your remote, simply unlock the vacation switch on the wall station. Problem solved. When the LED or the light bulb on your Linear garage door opener flashes six times, it means the motor has run for more than 30 seconds. Linear garage door openers have been designed to know how long it takes to fully open or close a garage door, and the maximum time it takes is about 30 seconds. When it exceeds that, the lights will flash six times. Call a Linear garage door opener expert in your area to come and fix it. This is usually a mechanical or electrical failure and requires an expert to handle it. When the LED or the light bulb on your Linear garage door opener flashes seven times, it means the encoder has detected an error. Two things can happen when this error is detected. It is either the garage door reverses anytime you activate it, or it won't open at all. The first thing to check when this happens is an obstruction in the doorway. If there is anything under the garage door or closer to the doorway, if there is something there, chances are it is blocking the signal from the sender to the receiving sensor. And that is the reason why the door isn't closing. Get rid of anything in the doorway. The two sensors on each side of the door are supposed to face each other. So check if they are properly aligned. A simple way to do that is to take a look at the sensor with the two LEDs. That is the sending sensor. Both the green and red LEDs should be on. If the red LED is off, then the sensors are not aligned. If that's the case, then clean the lenses on both sensors. And then adjust the sensors so they can face each other. Continue tweaking and adjusting till the red LED turns back on. Also: Liftmaster Garage Door Opener Troubleshooting: Step-by-Step Guide When the LED or the light bulb on your Linear garage door opener flashes four times, it means the force of the opener is exceeded. Before we dive into the troubleshooting steps, you need to know what a garage door opener's force is, and why it's important. Force of a garage door opener refers to the strength it requires to drive the garage door up or down under normal conditions. Your Linear garage door opener does not lift the entire weight of the door up or down; the torsion spring does that. The opener's force simply gives it a push or pull. What causes the force to be exceeded? First, when the torsion spring is broken, secondly, when the garage door tracks are damaged, and thirdly when the door is unbalanced. When any of these problems occur, it will require an excessive amount of energy from the opener to lift the door, and that can damage your opener. So to prevent this from happening, your Linear garage door opener will shut down. Carry out these troubleshooting steps to get this problem fixed. It's important to have your door closed before you follow these steps. Pull the emergency cord down and towards the garage door opener. This will disconnect the garage door from the opener. Open the garage door manually, to about halfway. Now leave the door. For a balanced garage door, it should stay in that position without going up or down. If that's not the case, then your garage door is unbalanced. Now lift the garage door to its fully open position. The garage door should stay up when you leave it. Else it is unbalanced. Call a technician if your door is unbalanced. Attempting to balance your door on your own can lead to severe injury if you are not experienced. However, after troubleshooting and your garage door is in good condition, you may have to adjust the force factor of your garage door opener. Here's how to adjust the force factor for these particular models: LDC0800, LDC0850, and the LDC0852 Press and hold the Up and Down button on the back panel for 3 seconds. Both the green and red LED, as well as the opener lights, will flash twice. It means opener is in the Force Factor settings. Press the up button to increase the force factor, or the down button to decrease it. Press the Learn button to save changes. The lights will flash twice again to confirm changes have been saved. Perform the Safety Reversing Test after adjusting. Place a brick under the garage door, at a position where it is in the way of the door. When the door hits the brick, it must reverse within 2 seconds. If it doesn't, decrease the Force Factor and repeat the test till the door reverses. Here's how to adjust the force factor for these particular models: LD033, LD050, LS050, and LC075 Adjusting the Close Force Locate the open and close force adjustment dials on the sides of your opener To increase the Close Force, turn the Close Force Adjustment dial 1/8 turn at a time, in the clockwise direction, until the door closes fully without reversing. To decrease the Close Force, turn the Close Force Adjustment dial 1/8 turn at a time, counterclockwise until the door stops in the middle while going up. NB: Performing the Safety Reversing Test is a crucial step. Failure to do so may result in severe injury or even death if the force is set too high. Also, do not use the Force Adjustment to compensate for a Binding or Sticking door. Also: Chamberlain Garage Door Opener Troubleshooting: Step-by-Step Guide When the LED or the light bulb on your Linear garage door opener flashes five times, it means vacation mode has been activated; hence the garage door won't open. Linear garage door openers have a feature called vacation mode. This is a handy security feature for homeowners who are traveling, on vacation, or simply not at home. With this feature activated, no one can get access to your garage, not even with your remote. To be able to open your garage door with your remote, simply unlock the vacation switch on the wall station. Problem solved. When the LED or the light bulb on your Linear garage door opener flashes six times, it means the motor has run for more than 30 seconds. Linear garage door openers have been designed to know how long it takes to fully open or close a garage door, and the maximum time it takes is about 30 seconds. When it exceeds that, the lights will flash six times. Call a Linear garage door opener expert in your area to come and fix it. This is usually a mechanical or electrical failure and requires an expert to handle it. When the LED or the light bulb on your Linear garage door opener flashes seven times, it means the encoder has detected an error. Two things can happen when this error is detected. It is either the garage door reverses anytime you activate it, or it won't open at all. The first thing to check when this happens is an obstruction in the doorway. If there is anything under the garage door or closer to the doorway, if there is something there, chances are it is blocking the signal from the sender to the receiving sensor. And that is the reason why the door isn't closing. Get rid of anything in the doorway. The two sensors on each side of the door are supposed to face each other. So check if they are properly aligned. A simple way to do that is to take a look at the sensor with the two LEDs. That is the sending sensor. Both the green and red LEDs should be on. If the red LED is off, then the sensors are not aligned. If that's the case, then clean the lenses on both sensors. And then adjust the sensors so they can face each other. Continue tweaking and adjusting till the red LED turns back on. Also: Liftmaster Garage Door Opener Troubleshooting: Step-by-Step Guide When the LED or the light bulb on your Linear garage door opener flashes four times, it means the force of the opener is exceeded. Before we dive into the troubleshooting steps, you need to know what a garage door opener's force is, and why it's important. Force of a garage door opener refers to the strength it requires to drive the garage door up or down under normal conditions. Your Linear garage door opener does not lift the entire weight of the door up or down; the torsion spring does that. The opener's force simply gives it a push or pull. What causes the force to be exceeded? First, when the torsion spring is broken, secondly, when the garage door tracks are damaged, and thirdly when the door is unbalanced. When any of these problems occur, it will require an excessive amount of energy from the opener to lift the door, and that can damage your opener. So to prevent this from happening, your Linear garage door opener will shut down. Carry out these troubleshooting steps to get this problem fixed. It's important to have your door closed before you follow these steps. Pull the emergency cord down and towards the garage door opener. This will disconnect the garage door from the opener. Open the garage door manually, to about halfway. Now leave the door. For a balanced garage door, it should stay in that position without going up or down. If that's not the case, then your garage door is unbalanced. Now lift the garage door to its fully open position. The garage door should stay up when you leave it. Else it is unbalanced. Call a technician if your door is unbalanced. Attempting to balance your door on your own can lead to severe injury if you are not experienced. However, after troubleshooting and your garage door is in good condition, you may have to adjust the force factor of your garage door opener. Here's how to adjust the force factor for these particular models: LDC0800, LDC0850, and the LDC0852 Press and hold the Up and Down button on the back panel for 3 seconds. Both the green and red LED, as well as the opener lights, will flash twice. It means opener is in the Force Factor settings. Press the up button to increase the force factor, or the down button to decrease it. Press the Learn button to save changes. The lights will flash twice again to confirm changes have been saved. Perform the Safety Reversing Test after adjusting. Place a brick under the garage door, at a position where it is in the way of the door. When the door hits the brick, it must reverse within 2 seconds. If it doesn't, decrease the Force Factor and repeat the test till the door reverses. Here's how to adjust the force factor for these particular models: LD033, LD050, LS050, and LC075 Adjusting the Close Force Locate the open and close force adjustment dials on the sides of your opener To increase the Close Force, turn the Close Force Adjustment dial 1/8 turn at a time, in the clockwise direction, until the door closes fully without reversing. To decrease the Close Force, turn the Close Force Adjustment dial 1/8 turn at a time, counterclockwise until the door stops in the middle while going up. NB: Performing the Safety Reversing Test is a crucial step. Failure to do so may result in severe injury or even death if the force is set too high. Also, do not use the Force Adjustment to compensate for a Binding or Sticking door. Also: Chamberlain Garage Door Opener Troubleshooting: Step-by-Step Guide When the LED or the light bulb on your Linear garage door opener flashes five times, it means vacation mode has been activated; hence the garage door won't open. Linear garage door openers have a feature called vacation mode. This is a handy security feature for homeowners who are traveling, on vacation, or simply not at home. With this feature activated, no one can get access to your garage, not even with your remote. To be able to open your garage door with your remote, simply unlock the vacation switch on the wall station. Problem solved. When the LED or the light bulb on your Linear garage door opener flashes six times, it means the motor has run for more than 30 seconds. Linear garage door openers have been designed to know how long it takes to fully open or close a garage door, and the maximum time it takes is about 30 seconds. When it exceeds that, the lights will flash six times. Call a Linear garage door opener expert in your area to come and fix it. This is usually a mechanical or electrical failure and requires an expert to handle it. When the LED or the light bulb on your Linear garage door opener flashes seven times, it means the encoder has detected an error. Two things can happen when this error is detected. It is either the garage door reverses anytime you activate it, or it won't open at all. The first thing to check when this happens is an obstruction in the doorway. If there is anything under the garage door or closer to the doorway, if there is something there, chances are it is blocking the signal from the sender to the receiving sensor. And that is the reason why the door isn't closing. Get rid of anything in the doorway. The two sensors on each side of the door are supposed to face each other. So check if they are properly aligned. A simple way to do that is to take a look at the sensor with the two LEDs. That is the sending sensor. Both the green and red LEDs should be on. If the red LED is off, then the sensors are not aligned. If that's the case, then clean the lenses on both sensors. And then adjust the sensors so they can face each other. Continue tweaking and adjusting till the red LED turns back on. Also: Liftmaster Garage Door Opener Troubleshooting: Step-by-Step Guide When the LED or the light bulb on your Linear garage door opener flashes four times, it means the force of the opener is exceeded. Before we dive into the troubleshooting steps, you need to know what a garage door opener's force is, and why it's important. Force of a garage door opener refers to the strength it requires to drive the garage door up or down under normal conditions. Your Linear garage door opener does not lift the entire weight of the door up or down; the torsion spring does that. The opener's force simply gives it a push or pull. What causes the force to be exceeded? First, when the torsion spring is broken, secondly, when the garage door tracks are damaged, and thirdly when the door is unbalanced. When any of these problems occur, it will require an excessive amount of energy from the opener to lift the door, and that can damage your opener. So to prevent this from happening, your Linear garage door opener will shut down. Carry out these troubleshooting steps to get this problem fixed. It's important to have your door closed before you follow these steps. Pull the emergency cord down and towards the garage door opener. This will disconnect the garage door from the opener. Open the garage door manually, to about halfway. Now leave the door. For a balanced garage door, it should stay in that position without going up or down. If that's not the case, then your garage door is unbalanced. Now lift the garage door to its fully open position. The garage door should stay up when you leave it. Else it is unbalanced. Call a technician if your door is unbalanced. Attempting to balance your door on your own can lead to severe injury if you are not experienced. However, after troubleshooting and your garage door is in good condition, you may have to adjust the force factor of your garage door opener. Here's how to adjust the force factor for these particular models: LDC0800, LDC0850, and the LDC0852 Press and hold the Up and Down button on the back panel for 3 seconds. Both the green and red LED, as well as the opener lights, will flash twice. It means opener is in the Force Factor settings. Press the up button to increase the force factor, or the down button to decrease it. Press the Learn button to save changes. The lights will flash twice again to confirm changes have been saved. Perform the Safety Reversing Test after adjusting. Place a brick under the garage door, at a position where it is in the way of the door. When the door hits the brick, it must reverse within 2 seconds. If it doesn't, decrease the Force Factor and repeat the test till the door reverses. Here's how to adjust the force factor for these particular models: LD033, LD050, LS050, and LC075 Adjusting the Close Force Locate the open and close force adjustment dials on the sides of your opener To increase the Close Force, turn the Close Force Adjustment dial 1/8 turn at a time, in the clockwise direction, until the door closes fully without reversing. To decrease the Close Force, turn the Close Force Adjustment dial 1/8 turn at a time, counterclockwise until the door stops in the middle while going up. NB: Performing the Safety Reversing Test is a crucial step. Failure to do so may result in severe injury or even death if the force is set too high. Also, do not use the Force Adjustment to compensate for a Binding or Sticking door. Also: Chamberlain Garage Door Opener Troubleshooting: Step-by-Step Guide When the LED or the light bulb on your Linear garage door opener flashes five times, it means vacation mode has been activated; hence the garage door won't open. Linear garage door openers have a feature called vacation mode. This is a handy security feature for homeowners who are traveling, on vacation, or simply not at home. With this feature activated, no one can get access to your garage, not even with your remote. To be able to open your garage door with your remote, simply unlock the vacation switch on the wall station. Problem solved. When the LED or the light bulb on your Linear garage door opener flashes six times, it means the motor has run for more than 30 seconds. Linear garage door openers have been designed to know how long it takes to fully open or close a garage door, and the maximum time it takes is about 30 seconds. When it exceeds that, the lights will flash six times. Call a Linear garage door opener expert in your area to come and fix it. This is usually a mechanical or electrical failure and requires an expert to handle it. When the LED or the light bulb on your Linear garage door opener flashes seven times, it means the encoder has detected an error. Two things can happen when this error is detected. It is either the garage door reverses anytime you activate it, or it won't open at all. The first thing to check when this happens is an obstruction in the doorway. If there is anything under the garage door or closer to the doorway, if there is something there, chances are it is blocking the signal from the sender to the receiving sensor. And that is the reason why the door isn't closing. Get rid of anything in the doorway. The two sensors on each side of the door are supposed to face each other. So check if they are properly aligned. A simple way to do that is to take a look at the sensor with the two LEDs. That is the sending sensor. Both the green and red LEDs should be on. If the red LED is off, then the sensors are not aligned. If that's the case, then clean the lenses on both sensors. And then adjust the sensors so they can face each other. Continue tweaking and adjusting till the red LED turns back on. Also: Liftmaster Garage Door Opener Troubleshooting: Step-by-Step Guide When the LED or the light bulb on your Linear garage door opener flashes four times, it means the force of the opener is exceeded. Before we dive into the troubleshooting steps, you need to know what a garage door opener's force is, and why it's important. Force of a garage door opener refers to the strength it requires to drive the garage door up or down under normal conditions. Your Linear garage door opener does not lift the entire weight of the door up or down; the torsion spring does that. The opener's force simply gives it a push or pull. What causes the force to be exceeded? First, when the torsion spring is broken, secondly, when the garage door tracks are damaged, and thirdly when the door is unbalanced. When any of these problems occur, it will require an excessive amount of energy from the opener to lift the door, and that can damage your opener. So to prevent this from happening, your Linear garage door opener will shut down. Carry out these troubleshooting steps to get this problem fixed. It's important to have your door closed before you follow these steps. Pull the emergency cord down and towards the garage door opener. This will disconnect the garage door from the opener. Open the garage door manually, to about halfway. Now leave the door. For a balanced garage door, it should stay in that position without going up or down. If that's not the case, then your garage door is unbalanced. Now lift the garage door to its fully open position. The garage door should stay up when you leave it. Else it is unbalanced. Call a technician if your door is unbalanced. Attempting to balance your door on your own can lead to severe injury if you are not experienced. However, after troubleshooting and your garage door is in good condition, you may have to adjust the force factor of your garage door opener. Here's how to adjust the force factor for these particular models: LDC0800, LDC0850, and the LDC0852 Press and hold the Up and Down button on the back panel for 3 seconds. Both the green and red LED, as well as the opener lights, will flash twice. It means opener is in the Force Factor settings. Press the up button to increase the force factor, or the down button to decrease it. Press the Learn button to save changes. The lights will flash twice again to confirm changes have been saved. Perform the Safety Revers

clockwise one turn using a flat blade screwdriver. This will automatically force the door to go in reverse whenever it hits an obstruction, such as the driveway or ground. Find the open and close force adjustment dials on the opener's sides. Increase the Close Force by turning the Close Force Adjustment dial 1/8 turn at a time, in the clockwise direction. Do this until the door opens fully without stopping. If you want to decrease the Close Force, turn the Close Force Adjustment dial 1/8 turn at a time, counterclockwise. Do this until the door stops in the middle while going up. First find the open and close force adjustment dials on the opener's sides. Increase the Close Force, turn the Close Force Adjustment dial 1/8 turn at a time, in the clockwise direction, until the door closes fully without reversing. Decrease the Close Force by turning the Close Force Adjustment dial 1/8 turn at a time, counterclockwise, until the door stops in the middle and reverse while going down. To perform the Safety Reversing Test after adjusting, Put a brick under the garage door, at a position where it is in the way of the door. When the door hits the brick, it must reverse within 2 seconds. If it doesn't, decrease the Close Force and repeat test till the door reverses. Pull the emergency cord towards the garage door opener. Open the garage door manually but only halfway. Leave the door open, ensuring it stays in this position without going up. Lift the garage door to the fully opened position. The door should stay up when left. Failure to do this shows that it is unbalanced. There are several reasons that could be causing your garage door not to wok. Some of the most common include: The photo eye to the garage door may be blocked. This happens over years with accumulation of dirt. It could be an issue of power disruptions. Check the operator's power source for any issues. The torsion springs may be broken. Call the garage door repair expert as this is often accompanied by aloud banging sound. The remote may be malfunctioning. Several things may be wrong with your remote including: Being out of range. The motor's antenna may be damaged or blocked from the signal. Fix by ensuring it hangs down from the motor. The door opens with the wall switch. Simply change the remote battery. When all fails, reprogram the remote. You may be dealing with an issue of snapped or loosened cables. It could be an issue that requires sensitivity adjustments. The limit setting may be off. It is possible that something may be blocking the garage door. The door may be locked. It may be disconnected from the switch. First, the door won't have any motion even when you press the start button. You are likely to hear humming or buzzing noise. In some cases, there may be smoke released inside the garage. Do not be alarmed since this is a common occurrence. Start by checking the sensors. In case your garage door refuses to close all the way, it's probably an issue with your sensors. Start with sensors always. Align the sensors if they keep blinking. Check the Tracks and Rollers. There should be no obstructions or blockages. Check the Trolley. Check to see that the trolley is not in bypass mode. Pull the rope towards the door to allow the trolley to latch properly. Check Your Remote. It is possible that the remote batteries are dead. Check to ensure that they are in good condition and reprogram the remote as need arises. Adjust the Limit Screws. The screws may fail to retract, causing the challenge. Check your Manual. Always refer to the manual since it has all the answers. When the garage door keeps blinking and reacting in a certain way chances are that it is communicating something already captured in the manual. Read it. Manually close your garage door as you contact the technician to come have a look. Some of the errors may be beyond you. The garage remote fails to work because of many reasons. The most common ones include: Depleted remote batteries. Replace batteries and the remote will work again. Disrupted remote signal. The remote transmitter may be disrupted after replacing the battery. Make sure to check for range and also confirm that the antennae are not spoiled. Inspect and make necessary repairs. A locked button engagement can hinder the remote's working. Check the lock button to be sure that it is not engaged. Your remote may need reprogramming. Make sure to confirm this before calling in the technician. It is necessary to re-associate the remote especially if it has been used for a long time. A problem with the door control wiring could cause the remote to fail working. Test for such malfunctions by: Unplugging the opener and disconnecting the two wires from the motor. Reconnecting your machine to power, then clearing its memory and reprogramming all remote controls. Unplugging the device for a second time and reconnecting the control wiring to the motor. Locating the wall mounted controls and disconnecting the wiring. Using your garage door opener remote to test the functionality of your door. You may be dealing with a blown Ground Fault Interrupter (GFI). This is the feature responsible of protecting your home from any electrical faults. You roll in after a long day at work, press the garage door opener, and nothing happens. Inside the garage, you see the garage door opener flashing five times each time you push the opener button. Now what? Before you call in the garage repair team, your issue likely requires a little 'logic' in the form of a new logic board. But before you make the investment in a new logic board, take additional steps to troubleshoot the solution since there are other minor issues that could be to blame for the malfunction. One reason a garage door opener may fail to lift and lower is due to lack of power. However, if your light bulb comes on and you can see the warning light flashing five times, lack of power isn't your issue. Step 2 - Reset the System This seems to be the first step with anything electronic. Each model is a bit different, but resetting the system could solve the problem. This is typically done using a reset switch located on the garage door opener unit. Look on the side of the unit for the switch. Make sure you have stable footing when using a ladder. To find the proper reset process, look at the owner's manual in print or online. You can likely also find videos on the internet showing you how to complete the task. Typically though, it requires you sync the system with your wall-mounted keypad or handheld garage remote. Step 3 - Test Door Movement Manually If the problem persists, evaluate the movement of the door and condition of the rails. Disconnect the door from the automatic garage door opener. Then open and close the door manually, checking for any obstructions or catching spots as the wheels move through the tracks. Step 4 - Check Obstacle Sensors Although four (instead of five) flashes typically indicates an issue with the sensors, it's worth taking a quick look to see if it resolves the issue. Check the sensors located on either side of the door opening, near the bottom. If either one is blinking, that will stop the door from closing and cause it to go back up. Re-aim them at each other until you get a steady light from both—then try the door. Be sure no part of your body or other obstacle is in between the two sensors or the light will remain red instead of green. The RPM sensor is a likely culprit if you've made the evaluations above and the problem persists. RPM stands for revolutions per minute and this sensor can malfunction, especially if the system was taxed with continual work. If the automatic garage door opener is not working properly, there are several things you can do to troubleshoot the problem. 1. Check the sensors. 2. Check the tracks and rollers. 3. Check the remote. 4. Check the opener. 5. Check the power source. 6. Check the limit settings. 7. Check the emergency release. 8. Check the manual. 9. Check the wiring. 10. Check the antenna. 11. Check the battery. 12. Check the antenna. 13. Check the antenna. 14. Check the antenna. 15. Check the antenna. 16. Check the antenna. 17. Check the antenna. 18. Check the antenna. 19. Check the antenna. 20. Check the antenna. 21. Check the antenna. 22. Check the antenna. 23. Check the antenna. 24. Check the antenna. 25. Check the antenna. 26. Check the antenna. 27. Check the antenna. 28. Check the antenna. 29. Check the antenna. 30. Check the antenna. 31. Check the antenna. 32. Check the antenna. 33. Check the antenna. 34. Check the antenna. 35. Check the antenna. 36. Check the antenna. 37. Check the antenna. 38. Check the antenna. 39. Check the antenna. 40. Check the antenna. 41. Check the antenna. 42. Check the antenna. 43. Check the antenna. 44. Check the antenna. 45. Check the antenna. 46. Check the antenna. 47. Check the antenna. 48. Check the antenna. 49. Check the antenna. 50. Check the antenna. 51. Check the antenna. 52. Check the antenna. 53. Check the antenna. 54. Check the antenna. 55. Check the antenna. 56. Check the antenna. 57. Check the antenna. 58. Check the antenna. 59. Check the antenna. 60. Check the antenna. 61. Check the antenna. 62. Check the antenna. 63. Check the antenna. 64. Check the antenna. 65. Check the antenna. 66. Check the antenna. 67. Check the antenna. 68. Check the antenna. 69. Check the antenna. 70. Check the antenna. 71. Check the antenna. 72. Check the antenna. 73. Check the antenna. 74. Check the antenna. 75. Check the antenna. 76. Check the antenna. 77. Check the antenna. 78. Check the antenna. 79. Check the antenna. 80. Check the antenna. 81. Check the antenna. 82. Check the antenna. 83. Check the antenna. 84. Check the antenna. 85. Check the antenna. 86. Check the antenna. 87. Check the antenna. 88. Check the antenna. 89. Check the antenna. 90. Check the antenna. 91. Check the antenna. 92. Check the antenna. 93. Check the antenna. 94. Check the antenna. 95. Check the antenna. 96. Check the antenna. 97. Check the antenna. 98. Check the antenna. 99. Check the antenna. 100. Check the antenna. 101. Check the antenna. 102. Check the antenna. 103. Check the antenna. 104. Check the antenna. 105. Check the antenna. 106. Check the antenna. 107. Check the antenna. 108. Check the antenna. 109. Check the antenna. 110. Check the antenna. 111. Check the antenna. 112. Check the antenna. 113. Check the antenna. 114. Check the antenna. 115. Check the antenna. 116. Check the antenna. 117. Check the antenna. 118. Check the antenna. 119. Check the antenna. 120. Check the antenna. 121. Check the antenna. 122. Check the antenna. 123. Check the antenna. 124. Check the antenna. 125. Check the antenna. 126. Check the antenna. 127. Check the antenna. 128. Check the antenna. 129. Check the antenna. 130. Check the antenna. 131. Check the antenna. 132. Check the antenna. 133. Check the antenna. 134. Check the antenna. 135. Check the antenna. 136. Check the antenna. 137. Check the antenna. 138. Check the antenna. 139. Check the antenna. 140. Check the antenna. 141. Check the antenna. 142. Check the antenna. 143. Check the antenna. 144. Check the antenna. 145. Check the antenna. 146. Check the antenna. 147. Check the antenna. 148. Check the antenna. 149. Check the antenna. 150. Check the antenna. 151. Check the antenna. 152. Check the antenna. 153. Check the antenna. 154. Check the antenna. 155. Check the antenna. 156. Check the antenna. 157. Check the antenna. 158. Check the antenna. 159. Check the antenna. 160. Check the antenna. 161. Check the antenna. 162. Check the antenna. 163. Check the antenna. 164. Check the antenna. 165. Check the antenna. 166. Check the antenna. 167. Check the antenna. 168. Check the antenna. 169. Check the antenna. 170. Check the antenna. 171. Check the antenna. 172. Check the antenna. 173. Check the antenna. 174. Check the antenna. 175. Check the antenna. 176. Check the antenna. 177. Check the antenna. 178. Check the antenna. 179. Check the antenna. 180. Check the antenna. 181. Check the antenna. 182. Check the antenna. 183. Check the antenna. 184. Check the antenna. 185. Check the antenna. 186. Check the antenna. 187. Check the antenna. 188. Check the antenna. 189. Check the antenna. 190. Check the antenna. 191. Check the antenna. 192. Check the antenna. 193. Check the antenna. 194. Check the antenna. 195. Check the antenna. 196. Check the antenna. 197. Check the antenna. 198. Check the antenna. 199. Check the antenna. 200. Check the antenna. 201. Check the antenna. 202. Check the antenna. 203. Check the antenna. 204. Check the antenna. 205. Check the antenna. 206. Check the antenna. 207. Check the antenna. 208. Check the antenna. 209. Check the antenna. 210. Check the antenna. 211. Check the antenna. 212. Check the antenna. 213. Check the antenna. 214. Check the antenna. 215. Check the antenna. 216. Check the antenna. 217. Check the antenna. 218. Check the antenna. 219. Check the antenna. 220. Check the antenna. 221. Check the antenna. 222. Check the antenna. 223. Check the antenna. 224. Check the antenna. 225. Check the antenna. 226. Check the antenna. 227. Check the antenna. 228. Check the antenna. 229. Check the antenna. 230. Check the antenna. 231. Check the antenna. 232. Check the antenna. 233. Check the antenna. 234. Check the antenna. 235. Check the antenna. 236. Check the antenna. 237. Check the antenna. 238. Check the antenna. 239. Check the antenna. 240. Check the antenna. 241. Check the antenna. 242. Check the antenna. 243. Check the antenna. 244. Check the antenna. 245. Check the antenna. 246. Check the antenna. 247. Check the antenna. 248. Check the antenna. 249. Check the antenna. 250. Check the antenna. 251. Check the antenna. 252. Check the antenna. 253. Check the antenna. 254. Check the antenna. 255. Check the antenna. 256. Check the antenna. 257. Check the antenna. 258. Check the antenna. 259. Check the antenna. 260. Check the antenna. 261. Check the antenna. 262. Check the antenna. 263. Check the antenna. 264. Check the antenna. 265. Check the antenna. 266. Check the antenna. 267. Check the antenna. 268. Check the antenna. 269. Check the antenna. 270. Check the antenna. 271. Check the antenna. 272. Check the antenna. 273. Check the antenna. 274. Check the antenna. 275. Check the antenna. 276. Check the antenna. 277. Check the antenna. 278. Check the antenna. 279. Check the antenna. 280. Check the antenna. 281. Check the antenna. 282. Check the antenna. 283. Check the antenna. 284. Check the antenna. 285. Check the antenna. 286. Check the antenna. 287. Check the antenna. 288. Check the antenna. 289. Check the antenna. 290. Check the antenna. 291. Check the antenna. 292. Check the antenna. 293. Check the antenna. 294. Check the antenna. 295. Check the antenna. 296. Check the antenna. 297. Check the antenna. 298. Check the antenna. 299. Check the antenna. 300. Check the antenna. 301. Check the antenna. 302. Check the antenna. 303. Check the antenna. 304. Check the antenna. 305. Check the antenna. 306. Check the antenna. 307. Check the antenna. 308. Check the antenna. 309. Check the antenna. 310. Check the antenna. 311. Check the antenna. 312. Check the antenna. 313. Check the antenna. 314. Check the antenna. 315. Check the antenna. 316. Check the antenna. 317. Check the antenna. 318. Check the antenna. 319. Check the antenna. 320. Check the antenna. 321. Check the antenna. 322. Check the antenna. 323. Check the antenna. 324. Check the antenna. 325. Check the antenna. 326. Check the antenna. 327. Check the antenna. 328. Check the antenna. 329. Check the antenna. 330. Check the antenna. 331. Check the antenna. 332. Check the antenna. 333. Check the antenna. 334. Check the antenna. 335. Check the antenna. 336. Check the antenna. 337. Check the antenna. 338. Check the antenna. 339. Check the antenna. 340. Check the antenna. 341. Check the antenna. 342. Check the antenna. 343. Check the antenna. 344. Check the antenna. 345. Check the antenna. 346. Check the antenna. 347. Check the antenna. 348. Check the antenna. 349. Check the antenna. 350. Check the antenna. 351. Check the antenna. 352. Check the antenna. 353. Check the antenna. 354. Check the antenna. 355. Check the antenna. 356. Check the antenna. 357. Check the antenna. 358. Check the antenna. 359. Check the antenna. 360. Check the antenna. 361. Check the antenna. 362. Check the antenna. 363. Check the antenna. 364. Check the antenna. 365. Check the antenna. 366. Check the antenna. 367. Check the antenna. 368. Check the antenna. 369. Check the antenna. 370. Check the antenna. 371. Check the antenna. 372. Check the antenna. 373. Check the antenna. 374. Check the antenna. 375. Check the antenna. 376. Check the antenna. 377. Check the antenna. 378. Check the antenna. 379. Check the antenna. 380. Check the antenna. 381. Check the antenna. 382. Check the antenna. 383. Check the antenna. 384. Check the antenna. 385. Check the antenna. 386. Check the antenna. 387. Check the antenna. 388. Check the antenna. 389. Check the antenna. 390. Check the antenna. 391. Check the antenna. 392. Check the antenna. 393. Check the antenna. 394. Check the antenna. 395. Check the antenna. 396. Check the antenna. 397. Check the antenna. 398. Check the antenna. 399. Check the antenna. 400. Check the antenna. 401. Check the antenna. 402. Check the antenna. 403. Check the antenna. 404. Check the antenna. 405. Check the antenna. 406. Check the antenna. 407. Check the antenna. 408. Check the antenna. 409. Check the antenna. 410. Check the antenna. 411. Check the antenna. 412. Check the antenna. 413. Check the antenna. 414. Check the antenna. 415. Check the antenna. 416. Check the antenna. 417. Check the antenna. 418. Check the antenna. 419. Check the antenna. 420. Check the antenna. 421. Check the antenna. 422. Check the antenna. 423. Check the antenna. 424. Check the antenna. 425. Check the antenna. 426. Check the antenna. 427. Check the antenna. 428. Check the antenna. 429. Check the antenna. 430. Check the antenna. 431. Check the antenna. 432. Check the antenna. 433. Check the antenna. 434. Check the antenna. 435. Check the antenna. 436. Check the antenna. 437. Check the antenna. 438. Check the antenna. 439. Check the antenna. 440. Check the antenna. 441. Check the antenna. 442. Check the antenna. 443. Check the antenna. 444. Check the antenna. 445. Check the antenna. 446. Check the antenna. 447. Check the antenna. 448. Check the antenna. 449. Check the antenna. 450. Check the antenna. 451. Check the antenna. 452. Check the antenna. 453. Check the antenna. 454. Check the antenna. 455. Check the antenna. 456. Check the antenna. 457. Check the antenna. 458. Check the antenna. 459. Check the antenna. 460. Check the antenna. 461. Check the antenna. 462. Check the antenna. 463. Check the antenna. 464. Check the antenna. 465. Check the antenna. 466. Check the antenna. 467. Check the antenna. 468. Check the antenna. 469. Check the antenna. 470. Check the antenna. 471. Check the antenna. 472. Check the antenna. 473. Check the antenna. 474. Check the antenna. 475. Check the antenna. 476. Check the antenna. 477. Check the antenna. 478. Check the antenna. 479. Check the antenna. 480. Check the antenna. 481. Check the antenna. 482. Check the antenna. 483. Check the antenna. 484. Check the antenna. 485. Check the antenna. 486. Check the antenna. 487. Check the antenna. 488. Check the antenna. 489. Check the antenna. 490. Check the antenna. 491. Check the antenna. 492. Check the antenna. 493. Check the antenna. 494. Check the antenna. 495. Check the antenna. 496. Check the antenna. 497. Check the antenna. 498. Check the antenna. 499. Check the antenna. 500. Check the antenna. 501. Check the antenna. 502. Check the antenna. 503. Check the antenna. 504. Check the antenna. 505. Check the antenna. 506. Check the antenna. 507. Check the antenna. 508. Check the antenna. 509. Check the antenna. 510. Check the antenna. 511. Check the antenna. 512. Check the antenna. 513. Check the antenna. 514. Check the antenna. 515. Check the antenna. 516. Check the antenna. 517. Check the antenna. 518. Check the antenna. 519. Check the antenna. 520. Check the antenna. 521. Check the antenna. 522. Check the antenna. 523. Check the antenna. 524. Check the antenna. 525. Check the antenna. 526. Check the antenna. 527. Check the antenna. 528. Check the antenna. 529. Check the antenna. 530. Check the antenna. 531. Check the antenna. 532. Check the antenna. 533. Check the antenna. 534. Check the antenna. 535. Check the antenna. 536. Check the antenna. 537. Check the antenna. 538. Check the antenna. 539. Check the antenna. 540. Check the antenna. 541. Check the antenna. 542. Check the antenna. 543. Check the antenna. 544. Check the antenna. 545. Check the antenna. 546. Check the antenna. 547. Check the antenna. 548. Check the antenna. 549. Check the antenna. 550. Check the antenna. 551. Check the antenna. 552. Check the antenna. 553. Check the antenna. 554. Check the antenna. 555. Check the antenna. 556. Check the antenna. 557. Check the antenna. 558. Check the antenna. 559. Check the antenna. 560. Check the antenna. 561. Check the antenna. 562. Check the antenna. 563. Check the antenna. 564. Check the antenna. 565. Check the antenna. 566. Check the antenna. 567. Check the antenna. 568. Check the antenna. 569. Check the antenna. 570. Check the antenna. 571. Check the antenna. 572. Check the antenna. 573. Check the antenna. 574. Check the antenna. 575. Check the antenna. 576. Check the antenna. 577. Check the antenna. 578. Check the antenna. 579. Check the antenna. 580. Check the antenna. 581. Check the antenna. 582. Check the antenna. 583. Check the antenna. 584. Check the antenna. 585. Check the antenna. 586. Check the antenna. 587. Check the antenna. 588. Check the antenna. 589. Check the antenna. 590. Check the antenna. 591. Check the antenna. 592. Check the antenna. 593. Check the antenna. 594. Check the antenna. 595. Check the antenna. 596. Check the antenna. 597. Check the antenna. 598. Check the antenna. 599. Check the antenna. 600. Check the antenna. 601. Check the antenna. 602. Check the antenna. 603. Check the antenna. 604. Check the antenna. 605. Check the antenna. 606. Check the antenna. 607. Check the antenna. 608. Check the antenna. 609. Check the antenna. 610. Check the antenna. 611. Check the antenna. 612. Check the antenna. 613. Check the antenna. 614. Check the antenna. 615. Check the antenna. 616. Check the antenna. 617. Check the antenna. 618. Check the antenna. 619. Check the antenna. 620. Check the antenna. 621. Check the antenna. 622. Check the antenna. 623. Check the antenna. 624. Check the antenna. 625. Check the antenna. 626. Check the antenna. 627. Check the antenna. 628. Check the antenna. 629. Check the antenna. 630. Check the antenna. 631. Check the antenna. 632. Check the antenna. 633. Check the antenna. 634. Check the antenna. 635. Check the antenna. 636. Check the antenna. 637. Check the antenna. 638. Check the antenna. 639. Check the antenna. 640. Check the antenna. 641. Check the antenna. 642. Check the antenna. 643. Check the antenna. 644. Check the antenna. 645. Check the antenna. 646. Check the antenna. 647. Check the antenna. 648. Check the antenna. 649. Check the antenna. 650. Check the antenna. 651. Check the antenna. 652. Check the antenna. 653. Check the antenna. 654. Check the antenna. 655. Check the antenna. 656. Check the antenna. 657. Check the antenna. 658. Check the antenna. 659. Check the antenna. 660. Check the antenna. 661. Check the antenna. 662. Check the antenna. 663. Check the antenna. 664. Check the antenna. 665. Check the antenna. 666. Check the antenna. 667. Check the antenna. 668. Check the antenna. 669. Check the antenna. 670. Check the antenna. 671. Check the antenna. 672. Check the antenna. 673. Check the antenna. 674. Check the antenna. 675. Check the antenna. 676. Check the antenna. 677. Check the antenna. 678. Check the antenna. 679. Check the antenna. 680. Check the antenna. 681. Check the antenna. 682. Check the antenna. 683. Check the antenna. 684. Check the antenna. 685. Check the antenna. 686. Check the antenna. 687. Check the antenna. 688. Check the antenna. 689. Check the antenna. 690. Check the antenna. 691. Check the antenna. 692. Check the antenna. 693. Check the antenna. 694. Check the antenna. 695. Check the antenna. 696. Check the antenna. 697. Check the antenna. 698. Check the antenna. 699. Check the antenna. 700. Check the antenna. 701. Check the antenna. 702. Check the antenna. 703. Check the antenna. 704. Check the antenna. 705. Check the antenna. 706. Check the antenna. 707. Check the antenna. 708. Check the antenna. 709. Check the antenna. 710. Check the antenna. 711. Check the antenna. 712. Check the antenna. 713. Check the antenna. 714. Check the antenna. 715. Check the antenna. 716. Check the antenna. 717. Check the antenna. 718. Check the antenna. 719. Check the antenna. 720. Check the antenna. 721. Check the antenna. 722. Check the antenna. 723. Check the antenna. 724. Check the antenna. 725. Check the antenna. 726. Check the antenna. 727. Check the antenna. 728. Check the antenna. 729. Check the antenna. 730. Check the antenna. 731. Check the antenna. 732. Check the antenna. 733. Check the antenna. 734. Check the antenna. 735. Check the antenna. 736. Check the antenna. 737. Check the antenna. 738. Check the antenna. 739. Check the antenna. 740. Check the antenna. 741. Check the antenna. 742. Check the antenna. 743. Check the antenna. 744. Check the antenna. 745. Check the antenna. 746. Check the antenna. 747. Check the antenna. 748. Check the antenna. 749. Check the antenna. 750. Check the antenna. 751. Check the antenna. 752. Check the antenna. 753. Check the antenna. 754. Check the antenna. 755. Check the antenna. 756. Check the antenna. 757. Check the antenna. 758. Check the antenna. 759. Check the antenna. 760. Check the antenna. 761. Check the antenna. 762. Check the antenna. 763. Check the antenna. 764. Check the antenna. 765. Check the antenna. 766. Check the antenna. 767. Check the antenna. 768. Check the antenna. 769. Check the antenna. 770. Check the antenna. 771. Check the antenna. 772. Check the antenna. 773. Check the antenna. 774. Check the antenna. 775. Check the antenna. 776. Check the antenna. 777. Check the antenna. 778. Check the antenna. 779. Check the antenna. 780. Check the antenna. 781. Check the antenna. 782. Check the antenna. 783. Check the antenna. 784. Check the antenna. 785. Check the antenna. 786. Check the antenna. 787. Check the antenna. 788. Check the antenna. 789. Check the antenna. 790. Check the antenna. 791. Check the antenna. 792. Check the antenna. 793. Check the antenna. 794. Check the antenna. 795. Check the antenna. 796. Check the antenna. 797. Check the antenna. 798. Check the antenna. 799. Check the antenna. 800. Check the antenna. 801. Check the antenna. 802. Check the antenna. 803. Check the antenna. 804. Check the antenna. 805. Check the antenna. 806. Check the antenna. 807. Check the antenna. 808. Check the antenna. 809. Check the antenna. 810. Check the antenna. 811. Check the antenna. 812. Check the antenna. 813. Check the antenna. 814. Check the antenna. 815. Check the antenna. 816. Check the antenna. 817. Check the antenna. 818. Check the antenna. 819. Check the antenna. 820. Check the antenna. 821. Check the antenna. 822. Check the antenna. 823. Check the antenna. 824. Check the antenna. 825. Check the antenna. 826. Check the antenna. 827. Check the antenna. 828. Check the antenna. 829. Check the antenna. 830. Check the antenna. 831. Check the antenna. 832. Check the antenna. 833. Check the antenna. 834. Check the antenna. 835. Check the antenna. 836. Check the antenna. 837. Check the antenna. 838. Check the antenna. 839. Check the antenna. 840. Check the antenna. 841. Check the antenna. 842. Check the antenna. 843. Check the antenna. 844. Check the antenna. 845. Check the antenna. 846. Check the antenna. 847. Check the antenna. 848. Check the antenna. 849. Check the antenna. 850. Check the antenna. 851. Check the antenna. 852. Check the antenna. 853. Check the antenna. 854. Check the antenna. 855. Check the antenna. 856. Check the antenna. 857. Check the antenna. 858. Check the antenna. 859. Check the antenna. 860. Check the antenna. 861. Check the antenna. 862. Check the antenna. 863. Check the antenna. 864. Check the antenna. 865. Check the antenna. 866. Check the antenna. 867. Check the antenna. 868. Check the antenna. 869. Check the antenna. 870. Check the antenna. 871. Check the antenna. 872. Check the antenna. 873. Check the antenna. 874. Check the antenna. 875. Check the antenna. 876. Check the antenna. 877. Check the antenna. 878. Check the antenna. 879. Check the antenna. 880. Check the antenna. 881. Check the antenna. 882. Check the antenna. 883. Check the antenna. 884. Check the antenna. 885. Check the antenna. 886. Check the antenna. 887. Check the antenna. 888. Check the antenna. 889. Check the antenna. 890. Check the antenna. 891. Check the antenna. 892. Check the antenna. 893. Check the antenna. 894. Check the antenna. 895. Check the antenna. 896. Check the antenna. 897. Check the antenna. 898. Check the antenna. 899. Check the antenna. 900. Check the antenna. 901. Check the antenna. 902. Check the antenna. 903. Check the antenna. 904. Check the antenna. 905. Check the antenna. 906. Check the antenna. 907. Check the antenna. 908. Check the antenna. 909. Check the antenna. 910. Check the antenna. 911. Check the antenna. 912. Check the antenna. 913. Check the antenna. 914. Check the antenna. 915. Check the antenna. 916. Check the antenna. 917. Check the antenna. 918. Check the antenna. 919. Check the antenna. 920. Check the antenna. 921. Check the antenna. 922. Check the antenna. 923. Check the antenna. 924. Check the antenna. 925. Check the antenna. 926. Check the antenna. 927. Check the antenna. 928. Check the antenna. 929. Check the antenna. 930. Check the antenna. 931. Check the antenna. 932. Check the antenna. 933. Check the antenna. 934. Check the antenna. 935. Check the antenna. 936. Check the antenna. 937. Check the antenna. 938. Check the antenna. 939. Check the antenna. 940. Check the antenna. 941. Check the antenna. 942. Check the antenna. 943. Check the antenna. 944. Check the antenna. 945. Check the antenna. 946. Check the antenna. 947. Check the antenna. 948. Check the antenna. 949. Check the antenna. 950. Check the antenna. 951. Check the antenna. 952. Check the antenna. 953. Check the antenna. 954. Check the antenna. 955. Check the antenna. 956. Check the antenna. 957. Check the antenna. 958. Check the antenna. 959. Check the antenna. 960. Check the antenna. 961. Check the antenna. 962. Check the antenna. 963. Check the antenna. 964. Check the antenna. 965. Check the antenna. 966. Check the antenna. 967. Check the antenna. 968. Check the antenna. 969. Check the antenna. 970. Check the antenna. 971. Check the antenna. 972. Check the antenna. 973. Check the antenna. 974. Check the antenna. 975. Check the antenna. 976. Check the antenna. 977. Check the antenna. 978. Check the antenna. 979. Check the antenna. 980. Check the antenna. 981. Check the antenna. 982. Check the antenna. 983. Check the antenna. 984. Check the antenna. 985. Check the antenna. 986. Check the antenna. 987. Check the antenna. 988. Check the antenna. 989. Check the antenna. 990. Check the antenna. 991. Check the antenna. 992. Check the antenna. 993. Check the antenna. 994. Check the antenna. 995. Check the antenna. 996. Check the antenna. 997. Check the antenna. 998. Check the antenna. 999. Check the antenna. 1000. Check the antenna. 1001. Check the antenna. 1002. Check the antenna. 1003. Check the antenna. 1004. Check the antenna. 1005. Check the antenna. 1006. Check the antenna. 1007. Check the antenna. 1008. Check the antenna. 1009. Check the antenna. 1010. Check the antenna. 1011. Check the antenna. 1012. Check the antenna. 1013. Check the antenna. 1014. Check the antenna. 1015. Check the antenna. 1016. Check the antenna. 1017. Check the antenna. 1018. Check the antenna. 1019. Check the antenna. 1020. Check the antenna. 1021. Check the antenna. 1022. Check the antenna. 1023. Check the antenna. 1024. Check the antenna. 1025. Check the antenna. 1026. Check the antenna. 1027. Check the antenna. 1028. Check the antenna. 1029. Check the antenna. 1030. Check the antenna. 1031. Check the antenna. 1032. Check the antenna. 1033. Check the antenna. 1034. Check the antenna. 1035. Check the antenna. 1036. Check the antenna. 1037. Check the antenna. 1038. Check the antenna. 1039. Check the antenna. 1040. Check the antenna. 1041. Check the antenna. 1042. Check the antenna. 1043. Check the antenna. 1044. Check the antenna. 1045. Check the antenna. 1046. Check the antenna. 1047. Check the antenna. 1048. Check the antenna. 1049. Check the antenna. 1050. Check the antenna. 1051. Check the antenna. 1052. Check the antenna. 1053. Check the antenna. 1054. Check the antenna. 1055. Check the antenna. 1056. Check the antenna. 1057. Check the antenna. 1058. Check the antenna. 1059. Check the antenna. 1060. Check the antenna. 1061. Check the antenna. 1062. Check the antenna. 1063. Check the antenna. 1064. Check the antenna. 1065. Check the antenna. 1066. Check the antenna. 1067. Check the antenna. 1068. Check the antenna. 1069. Check the antenna. 1070. Check the antenna. 1071. Check the antenna. 1072. Check the antenna. 1073. Check the antenna. 1074. Check the antenna. 1075. Check the antenna. 1076. Check the antenna. 1077. Check the antenna. 1078. Check the antenna. 1079. Check the antenna. 1080. Check the antenna. 1081. Check the antenna. 1082. Check the antenna. 1083. Check the antenna. 1084. Check the antenna. 1085. Check the antenna. 1086. Check the antenna. 1087. Check the antenna. 1088. Check the antenna. 1089. Check the antenna. 1090. Check the antenna. 1091. Check the antenna. 1092. Check the antenna. 1093. Check the antenna. 1094. Check the antenna. 1095. Check the antenna. 1096. Check the antenna. 1097. Check the antenna. 1098. Check the antenna. 1099. Check the antenna. 1100. Check the antenna. 1101. Check the antenna. 1102. Check the antenna. 1103. Check the antenna. 1104. Check the antenna. 1105. Check the antenna. 1106. Check the antenna. 1107. Check the antenna. 1108. Check the antenna. 1109. Check the antenna. 1110. Check the antenna. 1111. Check the antenna. 1112. Check the antenna. 1113. Check the antenna. 1114. Check the antenna. 1115. Check the antenna. 1116. Check the antenna. 1117. Check the antenna. 1118. Check the antenna. 1119. Check the antenna. 1120. Check the antenna. 1121. Check the antenna. 1122. Check the antenna. 1123. Check the antenna. 1124. Check the antenna. 1125. Check the antenna. 1126. Check the antenna. 1127. Check the antenna. 1128. Check the antenna. 1129. Check the antenna. 1130. Check the antenna. 1131. Check the antenna. 1132. Check the antenna. 1133. Check the antenna. 1134. Check the antenna. 1135. Check the antenna. 1136. Check the antenna. 1137. Check the antenna. 1138. Check the antenna. 1139. Check the antenna. 1140. Check the antenna. 1141. Check the antenna. 1142. Check the antenna. 1143. Check the antenna. 1144. Check the antenna. 1145. Check the antenna. 1146. Check the antenna. 1147. Check the antenna. 1148. Check the antenna. 1149. Check the antenna. 1150. Check the antenna. 1151. Check the antenna. 1152. Check the antenna. 1153. Check the antenna. 1154. Check the antenna. 1155. Check the antenna. 1156. Check the antenna. 1157. Check the antenna. 1158. Check the antenna. 1159. Check the antenna. 1160. Check the antenna. 1161. Check the antenna. 1162. Check the antenna. 1163. Check the antenna. 1164. Check the antenna. 1165. Check the antenna. 1166. Check the antenna. 1167. Check the antenna. 1168. Check the antenna. 1169. Check the antenna. 1170. Check the antenna. 1171. Check the antenna. 1172. Check the antenna. 1173. Check the antenna. 1174. Check the antenna. 1175. Check the antenna. 1176. Check the antenna. 1177. Check the antenna. 1178. Check the antenna. 1179. Check the antenna. 1180. Check the antenna. 1181. Check the antenna. 1182. Check the antenna. 1183. Check the antenna. 1184. Check the antenna. 1185. Check the antenna. 1186. Check the antenna.