

Click to verify



Combination locks use a system where each wheel corresponds to a number in the combination; turning the dial spins these wheels. The right combination aligns notches on the wheels, creating a gap that allows a metal bar (the fence) to drop, removing the obstacle for the bolt or hasp to move, thus unlocking the mechanism. This design, central to the functioning of combination locks, has been reliably securing valuables for nearly 100 years. Most combination locks use a wheel pack; a set of wheels that work together to 'know' the combination. All wheel packs are all designed around the same principle. The typical combination lock has a combination dial that is attached to a spindle, Inside the lock, the spindle runs through several wheels and a drive cam. The number of wheels in a wheel pack is determined by how many numbers are in the combination - one wheel for each number. When you turn the dial, the spindle turns the drive cam. Attached to the drive cam is a drive pin. As the cam turns, the drive pin eventually makes contact with a small tab on the adjacent wheel called the wheel fly. Each wheel has a wheel fly on each of its sides. The drive pin spins the first wheel until it makes contact with the wheel adjacent to it. This continues until all the wheels are spinning. This is known as picking up the wheels. Each wheel on the spindle has a notch cut into it. When the right combination is dialed, all the wheels and their notches line up perfectly. The fence is a small metal bar attached to a lever. The fence prevents the safe door from being opened without the combination being dialed. It does this by resting on the wheels and blocking the path of the bolt that secures the safe door. When all the wheels line up, their notches align to form a gap. In a padlock, this gap allows the hasp of the lock to release. In a safe, there is a piece called the fence resting just above the wheels. The fence falls into this gap under the force of its own weight. With the fence gone, the bolt can slide freely past and the safe can be opened. When all the wheels in the wheel pack are in the correct position, their notches align to form a gap. Under the force of its own weight, the fence falls into the gap allowing the safe to be opened. The wheel pack design has been used for almost 100 years. These instructions to dial a safe combination will work if you have the correct combination but stop to remember the dialing sequence, and the safe dial will not give out of alignment. If the instructions for dialing the safe are served throughout the open valley and would be happy to assist with any necessary safe jump to. These instructions pertain to how to open professional safes as safe dials such as AMSEC, SSG and LeGard.Safes purchased at home clubs, discount stores can be different if they are non professional grade safes. Download pdf Instruction: Opening a 3-digit Combination Safe. 1) Spin the dial left (CCW) at least four times and stop on the first number of the combination. The first number should be directly under the opening mark. First number: _____. 2) Spin the dial right (CW) and stop on the second number the 3rd time the number comes under the opening mark. Second number: _____. 3) Spin the dial left (CCW) and stop on the third number the 2nd time the number comes under the opening mark. Third number: _____. 4) Spin the dial right until the dial stops by itself. If the dial does not stop turning, the combination may be incorrect. 5) Open the safe. How to Open a Safe with 3 Number Combination These instructions pertain to dial safes that have a 4 digit combination. Download pdf Instructions: Dialing a 4-Digit Combination Safe. 1) Start by turning the dial to the right a minimum of 4 turns and stop on the first number. First number: _____. 2) Turn the dial to the left passing the second number twice, stopping on the third time. Second number: _____. 3) Turn the dial to the right passing the third number once, stopping on the number the next time. Third number: _____. 4) Turn the dial to the left to the fourth number and stop. Fourth number: _____. 5) Open the safe. How to Open a 4-Digit Combination Safe How to Change a Safe Combination How Safe Locks Work Have you ever found yourself in front of a mysterious combination lock? Perhaps it was guarding a secret chest rumored to be filled with ancient treasures or securing the entrance to a forgotten underground lair. Whatever the case, these intriguing contraptions have captivated our imaginations with their enigmatic secrets. But fear not, intrepid reader, for today we embark on a journey into the depths of mechanical marvels to unravel the inner workings of a combination lock. Prepare to have your curiosity satisfied as we shed light on the intricate mechanics behind these fascinating devices, revealing the secrets that lie within their circular prisons. Table of Contents The Inner Workings of a Combination LockUnlocking the mysteries behind a combination lock reveals a fascinating world of inner workings. Unlike conventional padlocks that require a physical key, a combination lock relies on a series of numbers or symbols to grant access. These sleek and compact devices are widely used to secure various belongings, ranging from school lockers to high-security safes. At the heart of a combination lock lies a complex mechanism known as the tumbler wheel. Composed of multiple disks stacked on top of each other, this ingenious system is what enables the lock to function. Each disk has notches, and when aligned properly with corresponding disks, they create a pathway for the lock to open. The outer dial of the lock is used to turn the disks, engaging them in the correct sequence. Combination locks often employ certain security features to deter unauthorized access. Most commonly, these include a false gate and anti-shim technology. The false gate presents an obstacle, making it challenging for anyone attempting to feel their way to unlock the device. On the other hand, anti-shim technology prevents the use of a thin metal strip, known as a shim, from bypassing the mechanism. These additional layers of security contribute to the reliability of combination locks, offering peace of mind in a compact, reliable package. Briefly summarized, consist of: a set of discrete disks stacked together, known as the tumbler wheel mechanism. Notches on each disk, creating a pathway for the lock to open when aligned correctly. An outer dial used to rotate the disks in the correct sequence. Exploring the Intricacies of the Locking MechanismThe locking mechanism is a fascinating component that plays a crucial role in various devices and systems. Understanding its intricacies not only unveils the mechanics behind the secure functioning of locks but also sheds light on the historical and technological advancements in this field. One of the primary elements of a locking mechanism is the tumblers, which are small pins or disks that prevent the lock from turning without the correct key. These tumblers, often made of hardened steel, are meticulously placed and aligned within the locks cylinder. When the correct key is inserted, it aligns the tumblers at different heights, allowing the lock to turn freely. The precision engineering involved in the creation of these tiny tumblers is a testament to human ingenuity. Furthermore, the locking mechanism can be enhanced with additional features like master key systems and complex keyways. Master key systems allow for multiple keys to operate a series of locks, providing convenience and flexibility while maintaining security. Additionally, intricate keyways, which are unique patterns cut into keys and locks, make them more tamper-resistant, further bolstering the protection they offer. Unraveling the Secrets of the Dial and WheelsUnlocking the enigmatic mysteries concealed within the intricate mechanisms of dials and wheels is a quest that has intrigued and captivated us for centuries. These silent yet essential components play a significant role in countless devices that surround us, from antique timepieces to modern control panels. Delving into the complexity of dials, we discover a symphony of numerical arrangements, symbols, and markers, each with a distinct purpose. They provide crucial visual cues, allowing us to decipher measurements, keep track of time, and navigate through a vast array of options. By skillfully rotating these small discs, information is revealed, choices are made, and connections are established. A similarly mesmerizing universe awaits those who dare to explore the realm of wheels. With their circular harmony of interlocking teeth, wheels transfer energy, transmit torque, and assist in precise adjustments. From steering wheels guiding us on endless highways to the ingenious gears of complex machinery, these marvels seamlessly blend form and function in a dance of mechanical elegance. As we embark on this luminous journey through the enigmatic domain of dials and wheels, prepare to become enchanted by the hidden symmetries, mathematical choreography, and tactile delights that lie beneath their surface. Join us as we unravel the secrets that shape our world, revealing the artistry, science, and untold tales that dwell within these quiet, unassuming heroes of mechanical ingenuity. Effective Methods for Setting and Resetting Your Combination When it comes to securing your valuable possessions, setting and resetting your combination lock is an essential skill. Whether you are safeguarding a gym locker, a bike lock, or a safe, mastering can provide peace of mind. Method 1: Traditional Dial Combination LockIf you own a traditional dial combination lock, follow these steps to set or reset the combination: 1. Turn the dial to the right until the number 12 is aligned with the opening mark. 2. Push the reset button (usually located on the back of the lock) and hold it down. 3. Turn the dial to the left, passing the number 12 twice, and stop on the number you want to set. 4. Release the reset button. Method 2: Modern Resettable Combination LockIf you have a resettable combination lock, the process may differ slightly. Start by locating the reset button, typically found on the bottom or side of the lock. Press and hold the reset button until you hear a click or see the locking mechanism disengage. Choose your desired combination by turning the dial to your desired numbers. Release the reset button, and your new combination is set. Remember, setting and resetting your combination is an important task that should be approached with care and precision. Take the time to read the manufacturer's instructions specific to your lock for more detailed guidance. Mastering the Art of Safely Opening a Combination Lock Understanding the BasicsTo become a master of opening combination locks, it is essential to have a solid understanding of the basics. Combination locks typically have a dial or a series of rotating discs that need to be aligned in a specific sequence to unlock them. Familiarize yourself with the locks components, including the dial, numbers, and notches. It is crucial to approach opening a combination lock with patience and precision. Step-by-Step Guide1. Familiarize yourself with the lock: Take a moment to examine the lock and its unique features. 2. Reset the lock: If the lock has already been used, reset it by rotating the dial clockwise for a full rotation. Stop when the first number of the combination lines up with the reference point. 3. Begin the combination: Starting with the first number of the combination, turn the dial clockwise until the reference point reaches that number. 4. Continue with the remaining numbers: Repeat the process for the remaining numbers, turning the dial counterclockwise and moving it past the reference point until the second and third numbers align. 5. Apply pressure: Once all the numbers have been aligned, apply gentle pressure to the shackle while turning the dial clockwise. If you feel resistance, make slight adjustments to the numbers until the lock disengages. 6. Practice makes perfect: Opening combination locks is a skill that improves with practice. Experiment with different lock variations and challenge yourself to become more adept. Tips and TricksRemember your combination by creating an acronym or visualizing a pattern connected to the numbers. When turning the dial, always go to the right until you reach the desired number. Apply consistent and steady pressure to the shackle while turning the dial. If you encounter difficulty, start over and go through the steps again. Patience and precision are key. Always ensure you have permission or authority to open the lock. With consistent practice and a good understanding of the basics, you'll soon find yourself effortlessly unlocking combination locks. Remember, practice makes perfect! Q&AHow does a combination lock work?A combination lock works by using a series of rotating disks or wheels, each with notches or teeth on them. When the correct combination is entered, the notches align, allowing the lock to be opened. What materials are combination locks typically made of?Combination locks are commonly made with brass, steel, or aluminum. The choice of material depends on factors such as durability, strength, and cost. What is the purpose of the combination?The combination in a combination lock is used to align the notches or teeth within the locks mechanism. When these notches are perfectly aligned, the lock can be opened. Can combination locks have more than one combination?Yes, some combination locks can be programmed to have multiple combinations. This feature is often used in commercial settings, where access needs to be granted to multiple individuals or groups. How secure are combination locks?The security of a combination lock depends on various factors, including the complexity of the combination, the strength of the materials used in the locks construction, and the overall design. While combination locks can provide a reasonable level of security, they can be vulnerable to skilled lock pickers or those who attempt to guess the combination. Can combination locks be reset?Yes, many combination locks can be reset to a new combination. The process usually requires specific instructions to be followed, such as rotating the dials to certain positions while entering a code. It's important to refer to the lock's manual or manufacturer's instructions for the proper reset procedure. Why are combination locks commonly used in various settings?Combination locks are popular because they offer a convenient and keyless method of securing belongings. They are commonly used in lockers, safes, briefcases, and bicycle locks, as they eliminate the need to carry or keep track of keys. Additionally, combination locks are often more resistant to wear and tear compared to key-operated locks. The Way ForwardAs we conclude this journey into the depths of the mechanical wonder known as the combination lock, we can't help but marvel at the intricate dance of gears, tumblers, and rotors working seamlessly to protect our prized possessions. From its humble beginnings in ancient civilizations to its modern-day metamorphosis, this ingenious contraption has evolved to become a symbol of security and reliability. Now armed with the knowledge of its inner workings, we can appreciate the symphony of precision that unfolds each time we manipulate those elusive digits. The hypnotic clicks and resolute satisfaction that come from aligning the notches and revealing the secret code remind us of the extraordinary mechanical ballet happening in that minuscule space. While its mechanics may seem intimidating at first, the beauty of the combination lock lies in its simplicity, an elegant fusion of art and science. It is a testament to human ingenuity, our desire to protect what is dear to us, and our unyielding pursuit of finding solutions to life's challenges. So the next time you find yourself turning the dials of a combination lock, take a moment to appreciate the ingenious design flawlessly executed by an army of meticulously crafted components. Reflect on the ancient wisdom and the countless hands that have refined and shaped this timeless piece of security. From the astonishing secrets locked away in ancient Egyptian tombs to the secure sanctums of our modern world, the combination lock has stood the test of time. It is a silent guardian, a steadfast companion, always ready to lend us its daunting, yet comforting presence in times of need. As we bid farewell to the world of combination lock mechanics, we leave you with a newfound admiration for this unassuming hero of security, and a gentle reminder of the artistry of invention that makes our lives a little safer. As an affiliate, my content may include affiliate links to products I personally use and recommend. By taking action, like subscribing or making a purchase, you'll be supporting my work and fueling my deep cravings for the next big thing. Win-win, right? Want to read more? Check out our Affiliate Disclosure page. In order to do great work with safe locks, perhaps the most important thing to know is how the locks work. Whether you're diagnosing a malfunction, opening a safe with an unknown combination or performing maintenance or repairs, a thorough understanding of lock functionality is likely to take you much further than any other information you could get your hands on. So, in the interest of furthering education on that topic, this article will document the operational functionality of a few locks. These are combination locks that I currently have in my possession: a Kromer 8567, a Diebold 900, and an Ico 6731. They are similar in function, in that each is a three-wheel, direct-drive combination lock of fairly typical high-level design. But even among these locks, there are significant differences that safe technicians should recognize. KROMER 8567 The Kromer 8567 appears in Figure 1 with its original black, textured paint. Figure 2 shows the inside. The lock cases interior has its original red paint job, but I've embellished most of the other parts to make them a little more fun to look at. An exploded view can be seen in Figure 3, with each part labeled by letter. * Each wheel is numbered according to which portion of the combination it applies. The first number of the combination is determined by wheel 1, the second by wheel 2, and so on. This is an industry-wide standard. Kromer stamped these numbers on the wheels of their locks, but the only difference between wheels 2 and 3 is the stamped number. I number each fly according to the number of the wheel in which it is installed. Parts C through H are known collectively as the wheel-pack. Now lets examine some critical sub-components of certain parts. Figures 4 and 5 show the lock case and fence lever. Notice that each of the isolation washers has a small extension along its inner circumference. That extension goes into a groove in the wheel-post, preventing the isolation washers from rotating. They separate all of the other wheel-pack components from each other and also inhibit the transfer of motion between them. This inhibition is what distinguishes isolation washers from simple spacers. This lock's spacer (part B) seems to serve no purpose other than to reduce friction by preventing the wheels from rubbing the lock case. The lever post (K,2) extends through the lock-hole in a hole in the lock-bolt and the other hooked arm is the lever. Fifth, this and other modern safe locks incorporate a lock-bolt safety device (J). This detent is a spring-loaded steel pin (see QOL) that protrudes into either of two dimples in the lock-bolt, which are shown in Figure 17. One dimple corresponds with the locked position, in which the lock-bolt is hooked into the lever-post and into the lever-post channel (A,4), limiting the lock-bolts range of motion. That way the lock-bolt can neither enter the lock case completely nor exit it completely as long as the lever post is in place. Figure 6 shows a wheel. This one happens to be wheel 3. On this side of the wheel, there is a depression to make room for the wheels fly. The fly is free to rotate within this depression, without moving the wheel, until the fly contacts one of the two fly stops. Now look at the other side of that wheel, Figure 7, to see its integrated drive pin. Wheel 2 also has a drive pin, as does the drive cam. But note that wheel 1 has no drive pin. (It doesn't need one because wheel 1 doesn't drive any other wheels.) The dial spindle goes through the wheel-pack and threads into the drive cam. A spline key keeps the spindle and cam fastened together, as shown in Figure 8. The three-number combination is dialed as follows: Turn the dial left (counter-clockwise) till the fourth time that the first number aligns with the opening index on the dial ring. This aligns wheel 1s gate under the fence. When the dial and drive cam rotate counter-clockwise, the cams drive pin pushes fly 3 counter-clockwise. When the fly reaches the left fly stop of wheel 3, it pushes the wheel counter-clockwise. At some point before wheel 3 completes one full rotation, wheel 3s drive pin contacts fly 2. When fly 2 reaches the left fly stop of wheel 2, it pushes the wheel counter-clockwise. Sometimes within one rotation of wheel 2, the wheel contacts fly 1 and begins pushing it. When fly 1 reaches the left fly stop of wheel 1, it begins pushing wheel 1. At this point the drive cam has made no more than three rotations counter-clockwise, and all of the wheels are moving together. So the user can now be sure that he is moving wheel 1 and thus will be ready to stop the next time he reaches the 1st number of the combination. Turn the dial right until the third time that the second number aligns with the opening index. This aligns wheel 2s gate under the fence without moving wheel 1. When the dial and drive cam rotate counter-clockwise, wheel 2s drive pin pushes fly 3 counter-clockwise. At some point before wheel 2 completes one full rotation, wheel 2s drive pin contacts fly 1. When fly 1 reaches the left fly stop of wheel 1, it begins pushing wheel 1. At this point the drive cam has made no more than two full rotations clockwise, and wheels 3 and 2 are now moving together. So the user can now be sure that he is moving wheel 2 while leaving wheel 1 in place, and thus will be ready to stop the next time he reaches the 2nd number of the combination. Turn the dial left until the second time that the third number aligns with the opening index. This aligns wheel 3s gate under the fence without moving wheels 1 and 2. When the dial and drive cam rotate counter-clockwise, the cams drive pin pushes fly 3 counter-clockwise. When the fly reaches the left fly stop of wheel 3, it begins to push the wheel counter-clockwise. At this point the drive cam has made one full rotation counter-clockwise, and wheel 3 is now moving independently of the other wheels. The user will be ready to stop the next time he reaches the third number of the combination. Turn the dial right until it comes to a complete stop. This retracts the lock-bolt. When the dial and drive cam rotate clockwise, the cams gate aligns with the lever nose. This allows the lock cases integrated lever spring to press the fence lever into the drive cam. The fence is an integral part of the lever that cannot enter the wheel-pack unless every wheels gate is aligned directly under the fence. The lever nose, therefore, cannot fully enter the drive cams gate unless the correct combination has been dialed. Since the combination has already been dialed to align the wheel gates, the lever nose fully enters the cams gate and the lever side-steps the lever stop. When the cam rotates further clockwise, it pulls the lock-bolt into the lock case. The lock is now unlocked. Notice in the exploded view of this lock that all of the wheels and flies are separated from each other by isolation washers, which are unable to rotate. The isolation washers prevent these parts from transferring motion to each other through friction, as they should only be moved by contact between drive pins, flies, and fly stops. This is very important. If parts are moved by friction, then wheels wont stay where theyre parked. For example, wheel 1 may move when the lever is hooked in a hole in the lock-bolt and the other hooked arm is the lever. Fifth, this and other modern safe locks incorporate a lock-bolt safety device (J). This detent is a spring-loaded steel pin (see QOL) that protrudes into either of two dimples in the lock-bolt, which are shown in Figure 17. One dimple corresponds with the locked position, in which the lock-bolt is hooked into the lever-post and into the lever-post channel (A,4), limiting the lock-bolts range of motion. That way the lock-bolt can neither enter the lock case completely nor exit it completely as long as the lever post is in place. Figure 6 shows a wheel. This one happens to be wheel 3. On this side of the wheel, there is a depression to make room for the wheels fly. The fly is free to rotate within this depression, without moving the wheel, until the fly contacts one of the two fly stops. Now look at the other side of that wheel, Figure 7, to see its integrated drive pin. Wheel 2 also has a drive pin, as does the drive cam. But note that wheel 1 has no drive pin. (It doesn't need one because wheel 1 doesn't drive any other wheels.) The dial spindle goes through the wheel-pack and threads into the drive cam. A spline key keeps the spindle and cam fastened together, as shown in Figure 8. The three-number combination is dialed as follows: Turn the dial left (counter-clockwise) till the fourth time that the first number aligns with the opening index on the dial ring. This aligns wheel 1s gate under the fence. When the dial and drive cam rotate counter-clockwise, the cams drive pin pushes fly 3 counter-clockwise. When the fly reaches the left fly stop of wheel 3, it pushes the wheel counter-clockwise. At some point before wheel 3 completes one full rotation, wheel 3s drive pin contacts fly 2. When fly 2 reaches the left fly stop of wheel 2, it pushes the wheel counter-clockwise. Sometimes within one rotation of wheel 2, the wheel contacts fly 1 and begins pushing it. When fly 1 reaches the left fly stop of wheel 1, it begins pushing wheel 1. At this point the drive cam has made no more than three rotations counter-clockwise, and all of the wheels are moving together. So the user can now be sure that he is moving wheel 1 and thus will be ready to stop the next time he reaches the 1st number of the combination. Turn the dial right until the third time that the second number aligns with the opening index. This aligns wheel 2s gate under the fence without moving wheel 1. When the dial and drive cam rotate counter-clockwise, wheel 2s drive pin pushes fly 3 counter-clockwise. At some point before wheel 2 completes one full rotation, wheel 2s drive pin contacts fly 1. When fly 1 reaches the left fly stop of wheel 1, it begins pushing wheel 1. At this point the drive cam has made no more than two full rotations clockwise, and wheels 3 and 2 are now moving together. So the user can now be sure that he is moving wheel 2 while leaving wheel 1 in place, and thus will be ready to stop the next time he reaches the 2nd number of the combination. Turn the dial left until the second time that the third number aligns with the opening index. This aligns wheel 3s gate under the fence without moving wheels 1 and 2. When the dial and drive cam rotate counter-clockwise, the cams drive pin pushes fly 3 counter-clockwise. When the fly reaches the left fly stop of wheel 3, it begins to push the wheel counter-clockwise. At this point the drive cam has made one full rotation counter-clockwise, and wheel 3 is now moving independently of the other wheels. The user will be ready to stop the next time he reaches the third number of the combination. Turn the dial right until it comes to a complete stop. This retracts the lock-bolt. When the dial and drive cam rotate clockwise, the cams gate aligns with the lever nose. This allows the lock cases integrated lever spring to press the fence lever into the drive cam. The fence is an integral part of the lever that cannot enter the wheel-pack unless every wheels gate is aligned directly under the fence. The lever nose, therefore, cannot fully enter the drive cams gate unless the correct combination has been dialed. Since the combination has already been dialed to align the wheel gates, the lever nose fully enters the cams gate and the lever side-steps the lever stop. When the cam rotates further clockwise, it pulls the lock-bolt into the lock case. The lock is now unlocked. Notice in the exploded view of this lock that all of the wheels and flies are separated from each other by isolation washers, which are unable to rotate. The isolation washers prevent these parts from transferring motion to each other through friction, as they should only be moved by contact between drive pins, flies, and fly stops. This is very important. If parts are moved by friction, then wheels wont stay where theyre parked. For example, wheel 1 may move when the lever is hooked in a hole in the lock-bolt and the other hooked arm is the lever. Fifth, this and other modern safe locks incorporate a lock-bolt safety device (J). This detent is a spring-loaded steel pin (see QOL) that protrudes into either of two dimples in the lock-bolt, which are shown in Figure 17. One dimple corresponds with the locked position, in which the lock-bolt is hooked into the lever-post and into the lever-post channel (A,4), limiting the lock-bolts range of motion. That way the lock-bolt can neither enter the lock case completely nor exit it completely as long as the lever post is in place. Figure 6 shows a wheel. This one happens to be wheel 3. On this side of the wheel, there is a depression to make room for the wheels fly. The fly is free to rotate within this depression, without moving the wheel, until the fly contacts one of the two fly stops. Now look at the other side of that wheel, Figure 7, to see its integrated drive pin. Wheel 2 also has a drive pin, as does the drive cam. But note that wheel 1 has no drive pin. (It doesn't need one because wheel 1 doesn't drive any other wheels.) The dial spindle goes through the wheel-pack and threads into the drive cam. A spline key keeps the spindle and cam fastened together, as shown in Figure 8. The three-number combination is dialed as follows: Turn the dial left (counter-clockwise) till the fourth time that the first number aligns with the opening index on the dial ring. This aligns wheel 1s gate under the fence. When the dial and drive cam rotate counter-clockwise, the cams drive pin pushes fly 3 counter-clockwise. When the fly reaches the left fly stop of wheel 3, it pushes the wheel counter-clockwise. At some point before wheel 3 completes one full rotation, wheel 3s drive pin contacts fly 2. When fly 2 reaches the left fly stop of wheel 2, it pushes the wheel counter-clockwise. Sometimes within one rotation of wheel 2, the wheel contacts fly 1 and begins pushing it. When fly 1 reaches the left fly stop of wheel 1, it begins pushing wheel 1. At this point the drive cam has made no more than three rotations counter-clockwise, and all of the wheels are moving together. So the user can now be sure that he is moving wheel 1 and thus will be ready to stop the next time he reaches the 1st number of the combination. Turn the dial right until the third time that the second number aligns with the opening index. This aligns wheel 2s gate under the fence without moving wheel 1. When the dial and drive cam rotate counter-clockwise, wheel 2s drive pin pushes fly 3 counter-clockwise. At some point before wheel 2 completes one full rotation, wheel 2s drive pin contacts fly 1. When fly 1 reaches the left fly stop of wheel 1, it begins pushing wheel 1. At this point the drive cam has made no more than two full rotations clockwise, and wheels 3 and 2 are now moving together. So the user can now be sure that he is moving wheel 2 while leaving wheel 1 in place, and thus will be ready to stop the next time he reaches the 2nd number of the combination. Turn the dial left until the second time that the third number aligns with the opening index. This aligns wheel 3s gate under the fence without moving wheels 1 and 2. When the dial and drive cam rotate counter-clockwise, the cams drive pin pushes fly 3 counter-clockwise. When the fly reaches the left fly stop of wheel 3, it begins to push the wheel counter-clockwise. At this point the drive cam has made one full rotation counter-clockwise, and wheel 3 is now moving independently of the other wheels. The user will be ready to stop the next time he reaches the third number of the combination. Turn the dial right until it comes to a complete stop. This retracts the lock-bolt. When the dial and drive cam rotate clockwise, the cams gate aligns with the lever nose. This allows the lock cases integrated lever spring to press the fence lever into the drive cam. The fence is an integral part of the lever that cannot enter the wheel-pack unless every wheels gate is aligned directly under the fence. The lever nose, therefore, cannot fully enter the drive cams gate unless the correct combination has been dialed. Since the combination has already been dialed to align the wheel gates, the lever nose fully enters the cams gate and the lever side-steps the lever stop. When the cam rotates further clockwise, it pulls the lock-bolt into the lock case. The lock is now unlocked. Notice in the exploded view of this lock that all of the wheels and flies are separated from each other by isolation washers, which are unable to rotate. The isolation washers prevent these parts from transferring motion to each other through friction, as they should only be moved by contact between drive pins, flies, and fly stops. This is very important. If parts are moved by friction, then wheels wont stay where theyre parked. For example, wheel 1 may move when the lever is hooked in a hole in the lock-bolt and the other hooked arm is the lever. Fifth, this and other modern safe locks incorporate a lock-bolt safety device (J). This detent is a spring-loaded steel pin (see QOL) that protrudes into either of two dimples in the lock-bolt, which are shown in Figure 17. One dimple corresponds with the locked position, in which the lock-bolt is hooked into the lever-post and into the lever-post channel (A,4), limiting the lock-bolts range of motion. That way the lock-bolt can neither enter the lock case completely nor exit it completely as long as the lever post is in place. Figure 6 shows a wheel. This one happens to be wheel 3. On this side of the wheel, there is a depression to make room for the wheels fly. The fly is free to rotate within this depression, without moving the wheel, until the fly contacts one of the two fly stops. Now look at the other side of that wheel, Figure 7, to see its integrated drive pin. Wheel 2 also has a drive pin, as does the drive cam. But note that wheel 1 has no drive pin. (It doesn't need one because wheel 1 doesn't drive any other wheels.) The dial spindle goes through the wheel-pack and threads into the drive cam. A spline key keeps the spindle and cam fastened together, as shown in Figure 8. The three-number combination is dialed as follows: Turn the dial left (counter-clockwise) till the fourth time that the first number aligns with the opening index on the dial ring. This aligns wheel 1s gate under the fence. When the dial and drive cam rotate counter-clockwise, the cams drive pin pushes fly 3 counter-clockwise. When the fly reaches the left fly stop of wheel 3, it pushes the wheel counter-clockwise. At some point before wheel 3 completes one full rotation, wheel 3s drive pin contacts fly 2. When fly 2 reaches the left fly stop of wheel 2, it pushes the wheel counter-clockwise. Sometimes within one rotation of wheel 2, the wheel contacts fly 1 and begins pushing it. When fly 1 reaches the left fly stop of wheel 1, it begins pushing wheel 1. At this point the drive cam has made no more than three rotations counter-clockwise, and all of the wheels are moving together. So the user can now be sure that he is moving wheel 1 and thus will be ready to stop the next time he reaches the 1st number of the combination. Turn the dial right until the third time that the second number aligns with the opening index. This aligns wheel 2s gate under the fence without moving wheel 1. When the dial and drive cam rotate counter-clockwise, wheel 2s drive pin pushes fly 3 counter-clockwise. At some point before wheel 2 completes one full rotation, wheel 2s drive pin contacts fly 1. When fly 1 reaches the left fly stop of wheel 1, it begins pushing wheel 1. At this point the drive cam has made no more than two full rotations clockwise, and wheels 3 and 2 are now moving together. So the user can now be sure that he is moving wheel 2 while leaving wheel 1 in place, and thus will be ready to stop the next time he reaches the 2nd number of the combination. Turn the dial left until the second time that the third number aligns with the opening index. This aligns wheel 3s gate under the fence without moving wheels 1 and 2. When the dial and drive cam rotate counter-clockwise, the cams drive pin pushes fly 3 counter-clockwise. When the fly reaches the left fly stop of wheel 3, it begins to push the wheel counter-clockwise. At this point the drive cam has made one full rotation counter-clockwise, and wheel 3 is now moving independently of the other wheels. The user will be ready to stop the next time he reaches the third number of the combination. Turn the dial right until it comes to a complete stop. This retracts the lock-bolt. When the dial and drive cam rotate clockwise, the cams gate aligns with the lever nose. This allows the lock cases integrated lever spring to press the fence lever into the drive cam. The fence is an integral part of the lever that cannot enter the wheel-pack unless every wheels gate is aligned directly under the fence. The lever nose, therefore, cannot fully enter the drive cams gate unless the correct combination has been dialed. Since the combination has already been dialed to align the wheel gates, the lever nose fully enters the cams gate and the lever side-steps the lever stop. When the cam rotates further clockwise, it pulls the lock-bolt into the lock case. The lock is now unlocked. Notice in the exploded view of this lock that all of the wheels and flies are separated from each other by isolation washers, which are unable to rotate. The isolation washers prevent these parts from transferring motion to each other through friction, as they should only be moved by contact between drive pins, flies, and fly stops. This is very important. If parts are moved by friction, then wheels wont stay where theyre parked. For example, wheel 1 may move when the lever is hooked in a hole in the lock-bolt and the other hooked arm is the lever. Fifth, this and other modern safe locks incorporate a lock-bolt safety device (J). This detent is a spring-loaded steel pin (see QOL) that protrudes into either of two dimples in the lock-bolt, which are shown in Figure 17. One dimple corresponds with the locked position, in which the lock-bolt is hooked into the lever-post and into the lever-post channel (A,4), limiting the lock-bolts range of motion. That way the lock-bolt can neither enter the lock case completely nor exit it completely as long as the lever post is in place. Figure 6 shows a wheel. This one happens to be wheel 3. On this side of the wheel, there is a depression to make room for the wheels fly. The fly is free to rotate within this depression, without moving the wheel, until the fly contacts one of the two fly stops. Now look at the other side of that wheel, Figure 7, to see its integrated drive pin. Wheel 2 also has a drive pin, as does the drive cam. But note that wheel 1 has no drive pin. (It doesn't need one because wheel 1 doesn't drive any other wheels.) The dial spindle goes through the wheel-pack and threads into the drive cam. A spline key keeps the spindle and cam fastened together, as shown in Figure 8. The three-number combination is dialed as follows: Turn the dial left (counter-clockwise) till the fourth time that the first number aligns with the opening index on the dial ring. This aligns wheel 1s gate under the fence. When the dial and drive cam rotate counter-clockwise, the cams drive pin pushes fly 3 counter-clockwise. When the fly reaches the left fly stop of wheel 3, it pushes the wheel counter-clockwise. At some point before wheel 3 completes one full rotation, wheel 3s drive pin contacts fly 2. When fly 2 reaches the left fly stop of wheel 2, it pushes the wheel counter-clockwise. Sometimes within one rotation of wheel 2, the wheel contacts fly 1 and begins pushing it. When fly 1 reaches the left fly stop of wheel 1, it begins pushing wheel 1. At this point the drive cam has made no more than three rotations counter-clockwise, and all of the wheels are moving together. So the user can now be sure that he is moving wheel 1 and thus will be ready to stop the next time he reaches the 1st number of the combination. Turn the dial right until the third time that the second number aligns with the opening index. This aligns wheel 2s gate under the fence without moving wheel 1. When the dial and drive cam rotate counter-clockwise, wheel 2s drive pin pushes fly 3 counter-clockwise. At some point before wheel 2 completes one full rotation, wheel 2s drive pin contacts fly 1. When fly 1 reaches the left fly stop of wheel 1, it begins pushing wheel 1. At this point the drive cam has made no more than two full rotations clockwise, and wheels 3 and 2 are now moving together. So the user can now be sure that he is moving wheel 2 while leaving wheel 1 in place, and thus will be ready to stop the next time he reaches the 2nd number of the combination. Turn the dial left until the second time that the third number aligns with the opening index. This aligns wheel 3s gate under the fence without moving wheels 1 and 2. When the dial and drive cam rotate counter-clockwise, the cams drive pin pushes fly 3 counter-clockwise. When the fly reaches the left fly stop of wheel 3, it begins to push the wheel counter-clockwise. At this point the drive cam has made one full rotation counter-clockwise, and wheel 3 is now moving independently of the other wheels. The user will be ready to stop the next time he reaches the third number of the combination. Turn the dial right until it comes to a complete stop. This retracts the lock-bolt. When the dial and drive cam rotate clockwise, the cams gate aligns with the lever nose. This allows the lock cases integrated lever spring to press the fence lever into the drive cam. The fence is an integral part of the lever that cannot enter the wheel-pack unless every wheels gate is aligned directly under the fence. The lever nose, therefore, cannot fully enter the drive cams gate unless the correct combination has been dialed. Since the combination has already been dialed to align the wheel gates, the lever nose fully enters the cams gate and the lever side-steps the lever stop. When the cam rotates further clockwise, it pulls the lock-bolt into the lock case. The lock is now unlocked. Notice in the exploded view of this lock that all of the wheels and flies are separated from each other by isolation washers, which are unable to rotate. The isolation washers prevent these parts from transferring motion to each other through friction, as they should only be moved by contact between drive pins, flies, and fly stops. This is very important. If parts are moved by friction, then wheels wont stay where theyre parked. For example, wheel 1 may move when the lever is hooked in a hole in the lock-bolt and the other hooked arm is the lever. Fifth, this and other modern safe locks incorporate a lock-bolt safety device (J). This detent is a spring-loaded steel pin (see QOL) that protrudes into either of two dimples in the lock-bolt, which are shown in Figure 17. One dimple corresponds with the locked position, in which the lock-bolt is hooked into the lever-post and into the lever-post channel (A,4), limiting the lock-bolts range of motion. That way the lock-bolt can neither enter the lock case completely nor exit it completely as long as the lever post is in place. Figure 6 shows a wheel. This one happens to be wheel 3. On this side of the wheel, there is a depression to make room for the wheels fly. The fly is free to rotate within this depression, without moving the wheel, until the fly contacts one of the two fly stops. Now look at the other side of that wheel, Figure 7, to see its integrated drive pin. Wheel 2 also has a drive pin, as does the drive cam. But note that wheel 1 has no drive pin. (It doesn't need one because wheel 1 doesn't drive any other wheels.) The dial spindle goes through the wheel-pack and threads into the drive cam. A spline key keeps the spindle and cam fastened together, as shown in Figure 8. The three-number combination is dialed as follows: Turn the dial left (counter-clockwise) till the fourth time that the first number aligns with the opening index on the dial ring. This aligns wheel 1s gate under the fence. When the dial and drive cam rotate counter-clockwise, the cams drive pin pushes fly 3 counter-clockwise. When the fly reaches the left fly stop of wheel 3, it pushes the wheel counter-clockwise. At some point before wheel 3 completes one full rotation, wheel 3s drive pin contacts fly 2. When fly 2 reaches the left fly stop of wheel 2, it pushes the wheel counter-clockwise. Sometimes within one rotation of wheel 2, the wheel contacts fly 1 and begins pushing it. When fly 1 reaches the left fly stop of wheel 1, it begins pushing wheel 1. At this point the drive cam has made no more than three rotations counter-clockwise, and all of the wheels are moving together. So the user can now be sure that he is moving wheel 1 and thus will be ready to stop the next time he reaches the 1st number of the combination. Turn the dial right until the third time that the second number aligns with the opening index. This aligns wheel 2s gate under the fence without moving wheel 1. When the dial and drive cam rotate counter-clockwise, wheel 2s drive pin pushes fly 3 counter-clockwise. At some point before wheel 2 completes one full rotation, wheel 2s drive pin contacts fly 1. When fly 1 reaches the left fly stop of wheel 1, it begins pushing wheel 1. At this point the drive cam has made no more than two full rotations clockwise, and wheels 3 and 2 are now moving together. So the user can now be sure that he is moving wheel 2 while leaving wheel 1 in place, and thus will be ready to stop the next time he reaches the 2nd number of the combination. Turn the dial left until the second time that the third number aligns with the opening index. This aligns wheel 3s gate under the fence without moving wheels 1 and 2. When the dial and drive cam rotate counter-clockwise, the cams drive pin pushes fly 3 counter-clockwise. When the fly reaches the left fly stop of wheel 3, it begins to push the wheel counter-clockwise. At this point the drive cam has made one full rotation counter-clockwise, and wheel 3 is now moving independently of the other wheels. The user will be ready to stop the next time he reaches the third number of the combination. Turn the dial right until it comes to a complete stop. This retracts the lock-bolt. When the dial and drive cam rotate clockwise, the cams gate aligns with the lever nose. This allows the lock cases integrated lever spring to press the fence lever into the drive cam. The fence is an integral part of the lever that cannot enter the wheel-pack unless every wheels gate is aligned directly under the fence. The lever nose, therefore, cannot fully enter the drive cams gate unless the correct combination has been dialed. Since the combination has already been dialed to align the wheel gates, the lever nose fully enters the cams gate and the lever side-steps the lever stop. When the cam rotates further clockwise, it pulls the lock-bolt into the lock case. The lock is now unlocked. Notice in the exploded view of this lock that all of the wheels and flies are separated from each other by isolation washers, which are unable to rotate. The isolation washers prevent these parts from transferring motion to each other through friction, as they should only be moved by contact between drive pins, flies, and fly stops. This is very important. If parts are moved by friction, then wheels wont stay where theyre parked. For example, wheel 1 may move when the lever is hooked in a hole in the lock-bolt and the other hooked arm is the lever. Fifth, this and other modern safe locks incorporate a lock-bolt safety device (J). This detent is a spring-loaded steel pin (see QOL) that protrudes into either of two dimples in the lock-bolt, which are shown in Figure 17. One dimple corresponds with the locked position, in which the lock-bolt is hooked into the lever-post and into the lever-post channel (A,4), limiting the lock-bolts range of motion. That way the lock-bolt can neither enter the lock case completely nor exit it completely as long as the lever post is in place. Figure 6 shows a wheel. This one happens to be wheel 3. On this side of the wheel, there is a depression to make room for the wheels fly. The fly is free to rotate within this depression, without moving the wheel, until the fly contacts one of the two fly stops. Now look at the other side of that wheel, Figure 7, to see its integrated drive pin. Wheel 2 also has a drive pin, as does the drive cam. But note that wheel 1 has no drive pin. (It doesn't need one because wheel 1 doesn't drive any other wheels.) The dial spindle goes through the wheel-pack and threads into the drive cam. A spline key keeps the spindle and cam fastened together, as shown in Figure 8. The three-number combination is dialed as follows: Turn the dial left (counter-clockwise) till the fourth time that the first number aligns with the opening index on the dial ring. This aligns wheel 1s gate under the fence. When the dial and drive cam rotate counter-clockwise, the cams drive pin pushes fly 3 counter-clockwise. When the fly reaches the left fly stop of wheel 3, it pushes the wheel counter-clockwise. At some point before wheel 3 completes one full rotation, wheel 3s drive pin contacts fly 2. When fly 2 reaches the left fly stop of wheel 2, it pushes the wheel counter-clockwise. Sometimes within one rotation of wheel 2, the wheel contacts fly 1 and begins pushing it. When fly 1 reaches the left fly stop of wheel 1, it begins pushing wheel 1. At this point the drive cam has made no more than three rotations counter-clockwise, and all of the wheels are moving together. So the user can now be sure that he is moving wheel 1 and thus will be ready to stop the next time he reaches the 1st number of the combination. Turn the dial right until the third time that the second number aligns with the opening index. This aligns wheel 2s gate under the fence without moving wheel 1. When the dial and drive cam rotate counter-clockwise, wheel 2s drive pin pushes fly 3 counter-clockwise. At some point before wheel 2 completes one full rotation, wheel 2s drive pin contacts fly 1. When fly 1 reaches the left fly stop of wheel 1, it begins pushing wheel 1. At this point the drive cam has made no more than two full rotations clockwise, and wheels 3 and 2 are now moving together. So the user can now be sure that he is moving wheel 2 while leaving wheel 1 in place, and thus will be ready to stop the next time he reaches the 2nd number of the combination. Turn the dial left until the second time that the third number aligns with the opening index. This aligns wheel 3s gate under the fence without moving wheels 1 and 2. When the dial and drive cam rotate counter-clockwise, the cams drive pin pushes fly 3 counter-clockwise. When the fly reaches the left fly stop of wheel 3, it begins to push the wheel counter-clockwise. At this point the drive cam has made one full rotation counter-clockwise, and wheel 3 is now moving independently of the other wheels. The user will be ready to stop the next time he reaches the third number of the combination. Turn the dial right until it comes to a complete stop. This retracts the lock-bolt. When the dial and drive cam rotate clockwise, the cams gate aligns with the lever nose. This allows the lock cases integrated lever spring to press the fence lever into the drive cam. The fence is an integral part of the lever that cannot enter the wheel-pack unless every wheels gate is aligned directly under the fence. The lever nose, therefore, cannot fully enter the drive cams gate unless the correct combination has been dialed. Since the combination has already been dialed to align the wheel gates, the lever nose fully enters the cams gate and the lever side-steps the lever stop. When the cam rotates further clockwise, it pulls the lock-bolt into the lock case. The lock is now unlocked. Notice in the exploded view of this lock that all of the wheels and flies are separated from each other by isolation washers, which are unable to rotate. The isolation washers prevent these parts from transferring motion to each other through friction, as they should only be moved by contact between drive pins, flies, and fly stops. This is very important. If parts are moved by friction, then wheels wont stay where theyre parked. For example, wheel 1 may move when the lever is hooked in a hole in the lock-bolt and the other hooked arm is the lever. Fifth, this and other modern safe locks incorporate a lock-bolt safety device (J). This detent is a spring-loaded steel pin (see QOL) that protrudes into either of two dimples in the lock-bolt, which are shown in Figure 17. One dimple corresponds with the locked position, in which the lock-bolt is hooked into the lever-post and into the lever-post channel (A,4), limiting the lock-bolts range of motion. That way the lock-bolt can neither enter the lock case completely nor exit it completely as long as the lever post is in place. Figure 6 shows a wheel. This one happens to be wheel 3. On this side of the wheel, there is a depression to make room for the wheels fly. The fly is free to rotate within this depression, without moving the wheel, until the fly contacts one of the two fly stops. Now look at the other side of that wheel, Figure 7, to see its integrated drive pin. Wheel 2 also has a drive pin, as does the drive cam. But note that wheel 1 has no drive pin. (It doesn't need one because wheel 1 doesn't drive any other wheels.) The dial spindle goes through the wheel-pack and threads into the drive cam. A spline key keeps the spindle and cam fastened together, as shown in Figure 8. The three-number combination is dialed as follows: Turn the dial left (counter-clockwise) till the fourth time that the first number aligns with the opening index on the dial ring. This aligns wheel 1s gate under the fence. When the dial and drive cam rotate counter-clockwise, the cams drive pin pushes fly 3 counter-clockwise. When the fly reaches the left fly stop of wheel 3, it pushes the wheel counter-clockwise. At some point before wheel 3 completes one full rotation, wheel 3s drive pin contacts fly 2. When fly 2 reaches the left fly stop of wheel 2, it pushes the wheel counter-clockwise. Sometimes within one rotation of wheel 2, the wheel contacts fly 1 and begins pushing it. When fly 1 reaches the left fly stop of wheel 1, it begins pushing wheel 1. At this point the drive cam has made no more than three rotations counter-clockwise, and all of the wheels are moving together. So the user can now be sure that he is moving wheel 1 and thus will be ready to stop the next time he reaches the 1st number of the combination. Turn the dial right until the third time that the second number aligns with the opening index. This aligns wheel 2s gate under the fence without moving wheel 1. When the dial and drive cam rotate counter-clockwise, wheel 2s drive pin pushes fly 3 counter-clockwise. At some point before wheel 2 completes one full rotation, wheel 2s drive pin contacts fly 1. When fly 1 reaches the left fly stop of wheel 1, it begins pushing wheel 1. At this point the drive cam has made no more than two full rotations clockwise, and wheels 3 and 2 are now moving together. So the user can now be sure that

in a safe. Beneath the pressure of its own weight, the fence slips into this breach. The bolt may now go easily through the gate, allowing the safe to be unlocked. Source: . A combination dial may be spun to input a combination to open a mechanical safe lock. The correct combination positions the locks tumbler in the proper position, allowing the door to be opened. Its straightforward, yet its effective. Traditional locks have been replaced with digital ones. Electronic safe locks function similarly to traditional locks, but they may be unlocked by inputting a 46-digit code on an electronic keypad. The keypad is powered by batteries. When the right combination is entered, the mechanism activates and the handle turns, allowing you to unlock the safes door. source: Safewell 1. Operational Simplicity For fire/burglary safes and gun safes, digital locking mechanisms are the most consumer-friendly sorts of locks accessible. They are simple to use and eliminate the need to memorize a combo or maintain track of a key. Rather, a safe lock may be configured with an easy-to-remember keycode that can be updated as required. Most safe versions have a light on the digital keypad, which makes it simpler to use in the dark. Mechanical safe locks, on the contrary, are difficult to operate since the combo must be exact when the dial is spun. Some safe users may find this challenging. Furthermore, turning a dial takes more time. Even if you get the combination correct the first time, unlocking the safe this way takes much longer than with an electronic lock. You cant alter the combo yourself; a safe locksmith has to do it. 2. Reliability Electronic locks are less likely to be damaged and survive longer than traditional locks. Theyve also progressed significantly over time, and theyre now just as dependable as classic mechanical safe locks. Check the UL certification on your safes lock if you really want to know how good it is. In the hardware sector, UL-listed safe locks are the holy grail. The lock has been carefully tested for effectiveness and durability, as indicated by this stamp of certification. 3. Enhanced Security Electronic locks are the industry leaders when it comes to added security attributes. You may add a variety of important secondary security checks to your safe using current technologies to improve its dependability and safety. source: Safewell 1. Price When weighing the advantages and disadvantages of electronic safe locks vs. mechanical safe locks, we must take pricing into account. For many people considering buying a safe, the price is a decision issue. Mechanical locks are the industry norm for the most part. While a particular safe manufacturer may provide a few safes with electronic locks as standard, the majority of safes will begin with a mechanical dial lock. Then youll have the option of upgrading to a battery-powered electronic lock, although this will usually come at a cost. 2. Replacing Batteries The batteries in digital safe locks, like other electrical devices, will need to be replaced from time to time. Absolutely guarantee, even if the battery dies, the electronic lock will remember your combination. In addition, if the battery power is getting low, the safety lock will offer you some form of warning. To learn more about your devices requirements and notification system, see the owners handbook. source: Safewell The registered fingerprint is used to unlock locked security safes. You may enrol more than one fingerprint to unlock the safe, giving you complete control over who has access to the fingerprint lock safe. The advantage of a biometric locking mechanism is that you dont have to memorize any codes or retain a key, so you dont have to worry about forgetting your code or misplacing your key. Its simple, secure, and tough to replicate your fingerprint to access your safe. Finger scan biometric system has been operational for quite some time and has shown to be a reliable and safe locking mechanism. Safewell has a large selection of safes with biometric finger scan locks. This locking mechanism has some major drawbacks that you should keep in mind. So there you go, all the safe locking mechanisms explained. Now, all that is left is for you to get quality safe with the locking mechanism that you are comfortable with. So, for whatever reason, you need the safe, we will provide it. Simply contact us and we are sure we can meet all your requirements. Page 2 Burglaries, floods, fires, and even insect damage may destroy objects that are safely placed behind secured doors in your house. Adding a layer of security in the shape of a digital home safe to those valuables is a sensible method to ensure that your essential documents and other belongings are genuinely secure. When it comes to choosing the proper safe for your house, there are several factors to consider. Aside from deciding on the sort of safe you want, the size you want, and other characteristics like fireproofing, you should think about how you want it to lock. For home safes, there are various distinct types of locking systems, each with its own function. The sort of lock you pick is mostly determined by your tastes. Do you have a knack for memorizing passwords and combinations? Do you like instant access? Consider this: When you need to extract your items, what would be the easiest to unlock? Keep reading to find out more! source: safewell The electronic lock has a terrible recognition for being problematic throughout the decades, and many folks avoid it as a result. Nevertheless, in recent times, these locks have shown to be quite trustworthy if you know what youre getting. It is highly recommended to only purchase a lock that has a visible name on it so that you are aware of what you are getting. A predefined code is input into an Electronic (Digital) lock, which is simply a plastic/metal pad. Once inside, the intrinsic lock is released, and the handle can be turned to rescind the bolts, allowing access to the safe. A predefined code is input into an Electronic (Digital) lock, which is simply a plastic/metal pad. Once inside, the intrinsic lock is released, and the handle can be turned to rescind the bolts, allowing access to the safe. There are an increasing number of biometric safe locks on the market, and as technology improves, so will these locks. Their dependability rating may not be what many individuals want in a safe that they need to open fast, but if you look around and are wise, it might be enough for your requirements. Biometric safe locks are opened with, as you have guessed, a part of the owners body. This could be face, retina and fingerprint. In most cases, fingerprint lock safe is much prevalent in gun safes, especially those that are smaller. Alt-Text: Mechanical Lock Safe The mechanical (dial) lock is noted for its dependability and longevity due to the absence of any electrical components. These locks are similar to those seen in classic films. Its also reminiscent of the lock you used in high school. To remove the final code, rotate the lock to the right 4-5 rounds, then to the left 4x for the initial code, 3x for the subsequent code, 2x for the third code, and then to the left till it catches (usually around 87). It takes some practice, but after a few tries, it becomes subsequent in nature. However, due to this procedure, accessing the contents of your safe takes substantially longer (about 45 seconds). If youre in a hurry, you may make it even longer since mistakes happen. This sort of lock is best for folks who dont need to get in quickly or who use their safe mostly for storage. Especially common for a gun safe with mechanical lock. Other than the tampering proof variants, which dont have almost as much leniency if a number is somewhat off, there arent many other types of a mechanical lock. source: Safewell A simple key-operated mechanical latch may be incredibly dependable, minimal-maintenance, and simple to use. For key-operated safes, a pick-resistant safe lock is normally used. Key lock safes are a good option for consumers who dont want to mess with a combo lock or an electronic access keypad. The only catch is that youll have to keep a record of where you keep your safes keys. Key-operated safes with dual locking are also accessible. They are more secure because they necessitate two keys to open the safe. Source: . A wheel pack is a series of wheels that operate together to know the combo in most combination locks. The design of all-wheel packs is based on the same premise. In a conventional combination lock, a keypad is connected to an axle. The spindle goes via numerous wheels and a driving cam inside the lock. A wheel packs amount of wheels is defined as the total number of digits in the combo one wheel for each digit. The wheel rotates the drive cam as you turn the dial. A drive pin is connected to the drive cam. The driving pin finally makes an impact with a little tab on the neighbouring wheel called the wheel fly as the cam rotates. On either side of each wheel is a wheel fly. The driving pin spins the first wheel until it collides with the neighbouring wheel. This process is repeated until all of the wheels are rotating. Picking up the wheels is the term for this. A notch is carved into each wheel on the axle. All of the wheels and their notches line up flawlessly when the appropriate combo is dialed in. A short metal bar linked to a lever serves as the fence. The gate prevents the safe from being accessed without first dialling the combination. It does this by sitting on the wheels and impeding the passage of the safe doors bolt. When all of the wheels are aligned, the notches generate a gap. This gap in a padlock permits the locks hasp to disengage. A section known as the fence rests immediately above the wheels in a safe. Beneath the pressure of its own weight, the fence slips into this breach. The bolt may now go easily through the gate, allowing the safe to be unlocked. Source: . A combination dial may be spun to input a combination to open a mechanical safe lock. The correct combination positions the locks tumbler in the proper position, allowing the door to be opened. Its straightforward, yet its effective. Traditional locks have been replaced with digital ones. Electronic safe locks function similarly to traditional locks, but they may be unlocked by inputting a 46-digit code on an electronic keypad. The keypad is powered by batteries. When the right combination is entered, the mechanism activates and the handle turns, allowing you to unlock the safes door. source: Safewell 1. Operational Simplicity For fire/burglary safes and gun safes, digital locking mechanisms are the most consumer-friendly sorts of locks accessible. They are simple to use and eliminate the need to memorize a combo or maintain track of a key. Rather, a safe lock may be configured with an easy-to-remember keycode that can be updated as required. Most safe versions have a light on the digital keypad, which makes it simpler to use in the dark. Mechanical safe locks, on the contrary, are difficult to operate since the combo must be exact when the dial is spun. Some safe users may find this challenging. Furthermore, turning a dial takes more time. Even if you get the combination correct the first time, unlocking the safe this way takes much longer than with an electronic lock. You cant alter the combo yourself; a safe locksmith has to do it. 2. Reliability Electronic locks are less likely to be damaged and survive longer than traditional locks. Theyve also progressed significantly over time, and theyre now just as dependable as classic mechanical safe locks. Check the UL certification on your safes lock if you really want to know how good it is. In the hardware sector, UL-listed safe locks are the holy grail. The lock has been carefully tested for effectiveness and durability, as indicated by this stamp of certification. 3. Enhanced Security Electronic locks are the industry leaders when it comes to added security attributes. You may add a variety of important secondary security checks to your safe using current technologies to improve its dependability and safety. source: Safewell 1. Price When weighing the advantages and disadvantages of electronic safe locks vs. mechanical safe locks, we must take pricing into account. For many people considering buying a safe, the price is a decision issue. Mechanical locks are the industry norm for the most part. While a particular safe manufacturer may provide a few safes with electronic locks as standard, the majority of safes will begin with a mechanical dial lock. Then youll have the option of upgrading to a battery-powered electronic lock, although this will usually come at a cost. 2. Replacing Batteries The batteries in digital safe locks, like other electrical devices, will need to be replaced from time to time. Absolutely guarantee, even if the battery dies, the electronic lock will remember your combination. In addition, if the battery power is getting low, the safety lock will offer you some form of warning. To learn more about your devices requirements and notification system, see the owners handbook. source: Safewell The registered fingerprint is used to unlock locked security safes. You may enrol more than one fingerprint to unlock the safe, giving you complete control over who has access to the fingerprint lock safe. The advantage of a biometric locking mechanism is that you dont have to memorize any codes or retain a key, so you dont have to worry about forgetting your code or misplacing your key. Its simple, secure, and tough to replicate your fingerprint to access your safe. Finger scan biometric system has been operational for quite some time and has shown to be a reliable and safe locking mechanism. Safewell has a large selection of safes with biometric finger scan locks. This locking mechanism has some major drawbacks that you should keep in mind. So there you go, all the safe locking mechanisms explained. Now, all that is left is for you to get quality safe with the locking mechanism that you are comfortable with. So, for whatever reason, you need the safe, we will provide it. Simply contact us and we are sure we can meet all your requirements.

Is combination lock safe. Safe combination lock mechanism. How do combination safe locks work. How does a combination safe work. How does a combination lock work.